

LAWN PUMP QUICK REFERENCE GUIDE

SEE INSTRUCTION MANUAL FOR COMPLETE DETAILS




For installation videos, scan with your smart phone.

1 TYPICAL INSTALLATION

NOTE: This pump is equipped with a 2 in. inlet for maximum water spray.


- 2 in. inlet (suction) opening can be reduced with some loss in performance. If reducing below 1-1/2 in., call factory.
- 1-1/2 in. outlet (discharge) pipe can be reduced with some loss in performance. If reducing below 1-1/4 in., call factory.




Questions, problems, missing parts?
Before returning to your retailer, call our customer service department at 1-800-742-5044, 7:30 a.m. - 5 p.m., EST, Monday - Friday.

2 WHAT CONTROLS WILL YOU USE WITH THIS PUMP?




NOTE: This pump can be used with a variety of controls. See control manufacturer's instructions for details.



3 CHECK YOUR BREAKER BOX



4 HERE'S HOW TO CHANGE THIS PUMP FROM 230V TO 115V




100% FACTORY TESTED

NOTE: Pump may show water stains as a result of factory water testing.


5 HOW TO PRIME YOUR PUMP

CAUTION: All pumps must be primed (filling the cavity with water) before they are first operated. This may take several gallons of water, as the inlet line will be filled in addition to the pump cavity. The longer the inlet line, the more water is required to prime.


1. Disconnect the outlet union and separate the pipe.




2. Remove priming plug with pressure gauge and the air relief plug on top of pump.




3. Slowly fill pump cavity until water comes out of the air relief hole.



4. Replace air relief plug and continue adding water to pump cavity until water comes out the open outlet pipe at the open union.



5. Wait 10 minutes to see if water level drops below the pipe tee. If level drops, check foot valve. If level stays constant, re-install the priming plug.



6. Reconnect union on outlet pipe. Open the ball valve (turn handle to line up with pipe), and then turn on breaker to start pump.

