

# Mighty-Seal<sup>™</sup> Sealing Reducing Washers (10XX-RT Series)

## **Application**

Bridgeport's, Patent-Pending, Mighty-Seal<sup>™</sup> Sealing Reducing Washers are used to maintain a wet-location seal when reducing the size of a knockout on a wet-location rated (NEMA 3R) enclosure.

# **Preparation**

- 1. Determine the proper trade size of reducing washers needed.
- 2. The Mighty-Seal<sup>™</sup> Sealing Reducing Washer **must** be paired with the same trade size, traditional reducing washer on the inside the enclosure.
- 3. The Mighty-Seal<sup>™</sup> Sealing Reducing Washer is meant to be placed on the outside of the box or enclosure while a traditional or unmolded reducing washer is located inside the enclosure. The unmolded portion of the washer is to face inwards towards the inside of the enclosure.

### **Installation**

#### Installation with a Fitting:

- 1. Install the Mighty-Seal<sup>™</sup> Sealing Reducing Washer onto the fitting. (See Image)
- 2. Continue to insert the fitting through the enclosure with the Mighty-Seal<sup>™</sup> Sealing Reducing Washer outside the enclosure and the steel plated washer located inside. Make sure both washers are centered in the knockout opening. (See Image)
- 3. While securing the fitting, tighten locknut hand tight, **plus two full additional turns** with channel lock pliers or locknut wrench to ensure a properly bonded connection. **Do not** use a hammer and screwdriver as the reducing washers will be forced out of position from the center of the enclosure knockout.

#### Installation with threaded Rigid or Intermediate Metal Conduit:

- 1. Thread a conduit locknut onto the conduit end until it stops. Make sure the locknut teeth are facing towards the enclosure.
- 2. Place the Mighty-Seal<sup>™</sup> Sealing Reducing Washer onto the conduit. (See Image)
- 3. Continue to insert the conduit through the enclosure and follow steps 2 & 3 in the previous instruction.



