



**KILLARK®**

## INSTALLATION, OPERATION & MAINTENANCE DATA SHEET

**TYPE SWB CONTROL STATIONS AND CONTROL PANELS**  
FOR USE IN CLASS I, DIV. 1 & 2, GROUPS C & D  
CLASS I, ZONES 1 & 2, GROUPS IIB, IIA  
CLASS II, DIV. 1 & 2, GROUPS E, F & G, CLASS III



## TYPE SWB CONTROL STATIONS AND CONTROL PANELS

### **CAUTION:**

Before installing, make sure you are compliant with area classifications, failure to do so may result in bodily injury, death and property damage. Do not attempt installation until you are familiar with the following procedures. All installation must comply with the applicable Electrical Code.

Make sure that the circuit is de-energized before starting installation or maintenance.

Verify that the installation is grounded. Failure to ground will create electrical shock hazards, which can cause serious injury and or death.

### **IMPORTANT:**

Please read these instructions carefully before installing or maintaining this equipment. Good electrical practices should be followed at all times and this data should be used as a guide only.

Technical information, advice and recommendations contained in these documents is based upon information that Killark believes to be reliable. All the information and advice contained in these documents is intended for use only by persons having been trained and possessing the requisite skill and know-how and to be used by such persons only at their own discretion and risk. The nature of these instructions is informative only and does not cover all of the details, variations or combinations in which this equipment may be used, its storage, delivery, installation, check out, safe operation and maintenance. Since conditions of use of the product are outside of the care, custody and control of Killark, the purchaser should determine the suitability of the product for his intended use, and assumes all risk and liability whatsoever in connection therewith.

**KILLARK®**

Chalmit

**Victor**  
Lighting

Vantage<sup>®</sup>  
Technology

RIGPOWER

**HAWKE**  
International

3940 Dr. Martin Luther King Drive  
St. Louis, MO 63113

P/N KIL00901308 FORM NO. K0569F ECO-3-011-12 R04/2012  
FORMULE NO. K0569F R04/2012

FOR USE WITH SWB SINGLE AND MULTIPLE GANG BACK BOXES;  
SWB-1, -2, -3, -4, -5, -6, -7, -8, -9, -10, -11, -12, -17, -18,  
-19, -20, -21, -31, -32, -34, -35, -36, -37, -38, -42, -45, -48 & -49.

COVER ASSEMBLIES (ONE REQUIRED PER GANG)  
A) SNAP SWITCHES SERIES XS  
B) PUSHBUTTONS SERIES XCS  
C) SELECTOR SWITCHES SERIES XCS  
D) PILOT LIGHTS SERIES XCS  
E) MANUAL MOTOR STARTERS SERIES XSD  
F) RECEPTACLES SERIES KRS-20, KRS-303, KRS-304  
G) BLANK COVER SERIES X-10

ENSEMBLES DE COUVERCLE (UN PAR SECTION)  
A) COMMUTATEURS A RESSORT SERIES XS  
B) BOUTONS-POUSSOIRS SERIES XCS  
C) COMMUTATEURS SELECTEURS SERIES XCS  
D) LAMPES TEMOINS SERIES XCS  
E) DEMARREURS MANUEL DE MOTEUR SERIES XSD  
F) PRISES DE COURANT SERIES KRS-20, KRS-303,  
KRS-304  
G) PLAQUE COUVERCLE SERIES X-10

## **1. DIRECTIONS FOR INSTALLATION**

1. Mount the back box by means of mounting lugs, install conduit nipple and sealing fittings one each to be installed on each conduit entrance or exit to the enclosure back box in Class I and Class II areas (Reference: Article 500 NEC) thread conduit into sealing fitting (**Note: for Class I areas the conduit should engage [5] full threads.**)
2. The conduit thread should be lubricated with a non-electrical insulating lubricant or pipe joint compound that will not promote corrosion or chemically attack aluminium.
3. After conduit system has been properly installed, pull the wires and make electrical connections as required. The electrical circuits and ground continuity should be checked with an instrument approved for the area. (Notice: connect only copper wire to this device).
4. All conduits entering or leaving the enclosure must be sealed within 18" of the enclosure with listed sealing fittings such as Killark "EY" or "EYS" sealing fittings.
5. Caution must be taken during installation to be sure that the ground flange flame joints of the cover and the box are not scratched, nicked or damaged.
6. Before assembly of the cover to the box, the mating ground surfaces of both the box and cover should be wiped clean to assure that the ground flame joint will be free of all foreign particles such as lint, dust or dirt.
7. After tightly bolting the cover assembly/assemblies to the enclosure all box to cover, flame joints should be checked with a 0.0015" thick feeler gauge such that the gauge will not enter the flame path more than 1/8" at any point.

**KILLARK®**



**Victor**  
Lighting

**Vantage**  
Technology



**HAWKE**  
International

3940 Dr. Martin Luther King Drive  
St. Louis, MO 63113


## 2. MAINTENANCE

All moving shafts should be lubricated occasionally to prevent binding. Only use a lubricant which is suitable for use with aluminium or stainless steel such as killark "LUBG" (general purpose) or "LUBT" (high temperature) lubricants. If devices are to be installed in corrosive areas which will attack aluminium alloys containing less than 0.4% copper (boxes and covers) and 303 stainless steel (mostly shafts), the device should be suitably protected from the corrosive material.

## 3. CAUTION

To prevent ignition of hazardous atmospheres, disconnect from the supply circuits before opening the enclosure; keep tightly closed while circuits are energized.

BOX IDENTIFICATION					
IDENT NO.	NO GANGS	CAT.NO	IDENT NO.	NO GANGS	CAT.NO
7	2	SWB- 7	21	5	SWB-21
8	2	SWB- 8	30	4	SWB-31
9	2	SWB- 9	32	6	SWB-32
10	2	SWB- 10	33	8	SWB-33
11	2	SWB- 11	34	10	SWB-34
12	2	SWB- 12	35	6	SWB-35
17	2	SWB- 17	36	9	SWB-36
18	2	SWB- 18	37	12	SWB-37
19	3	SWB- 19	38	15	SWB-38
20	4	SWB- 20			



**KILLARK®**

Chalmit

**Victor**  
Lighting

**Vantage®**  
Technology

**RIGPOWER**

**HAWKE**  
International

3940 Dr. Martin Luther King Drive  
St. Louis, MO 63113

P/N KIL00901308 FORM NO. K0569F ECO-3-011-12  
R04/2012 FORMULE NO. K0569F R04/2012

## **1. METHODE GENERALE D'INSTALLATION**

1. Monter le boitier au moyen des oreilles de fixation fournies. Installer le raccord et le raccord d'étanchéité, un de chaque sorte a visser sur chaque entrée ou sortie de tube vers l'enceinte, dans les endroits de Class I et Classe II (Reference: Article 500 Du Cen).  
**(Note: Pour les endroits de Classe I, le tube doit engager 5 filets complets).**
2. Les filets du tube doivent être lubrifiés avec un lubrifiant isolant non électrique, ou mastic pour joints de tuyaux qui n'encouragera pas la corrosion, ni n'attaquera chimiquement l'aluminium.
3. Après que le système de tubes aura été installé convenablement, tirer les fils et faites les raccords requis. il faut contrôler les circuits électriques et l'uniformité de la mise à la terre au moyen d'un appareil approuvé pour l'endroit. Note: Raccorder seulement des fils en cuivre à ce dispositif.
4. Tous les tubes entrant dans l'enceinte ou en sortant doivent être fermes à 18° de l'enceinte avec des raccords. d'étanchéité reportées tels que les raccords Killark "ey" ou "eys".
5. Il faut veiller pendant l'installation à ce que les joints à collet du couvercle et du boîtier ne soient ni éraflés, ni entaillés, ni endommagés. avant d'assembler le couvercle sur le boîtier, il faut essuyer les surfaces de mise à la terre correspondantes pour être sûr que le joint sera exempt de toute particule étrangère, telle que poussière, saleté ou charpie.
6. Après avoir bien boulonné les ensembles des couvercles sur l'enceinte, il faut vérifier tous les joints entre le boîtier et le couvercle avec un calibre d'épaisseur de 0.0015" (de sorte que le calibre ne pénètrera pas dans le joint de plus de 1/8" à n'importe quel point).

## **2. ENTRETIEN**

Tous les arbres mobiles doivent être lubrifiés à l'occasion pour empêcher tout coincement. Employer seulement un lubrifiant convenant à l'aluminium ou l'acier inoxydable, tel que Killark "lubg" (tout usage) ou "lubt" (hautes températures). Garder tous les collets propres et exempts d'éraflures.

Si les dispositifs doivent être installés dans des endroits corrosifs qui attaqueront les alliages d'aluminium contenant moins de 0.4% de cuivre (boîters et couvercles) et de l'acier inoxydable 303 (la plupart des arbres), il faut protéger le dispositif convenablement contre le matériau corrosif.

**KILLARK®**



**Victor**

**Vantage**  
Technology

**RIGPOWER**

**HAWKE**  
International

3940 Dr. Martin Luther King Drive  
St. Louis, MO 63113


P/N KIL00901308 FORM NO. K0569F ECO-3-011-12  
R04/2012 FORMULE NO. K0569F R04/2012

Page 4 of 5

### 3. MISE EN GARDE

Pour empêcher toute inflammation des atmosphères dragereuses, débrancher des circuits d'alimentation avant d'ouvrir l'enceinte. Garder bien fermé tant que les circuits sont sous tension.

IDENTIFICATION DU BOTHER					
NO. D'IDE NT	NO OF SECTIO NS	CAT.DE	NO.D'ID ENT	NO OF SECTIO NS	CA.DE
7	2	SWB- 7	21	5	SWB-21
8	2	SWB- 8	30	4	SWB-31
9	2	SWB- 9	32	6	SWB-32
10	2	SWB-10	33	8	SWB-33
11	2	SWB-11	34	10	SWB-34
12	2	SWB-12	35	6	SWB-35
17	2	SWB-17	36	9	SWB-36
18	2	SWB-18	37	12	SWB-37
19	3	SWB-19	38	15	SWB-38
20	4	SWB-20			



**KILLARK®**

Chalmit

**Victor**

Lighting

**Vantage®**  
Technology

**RIGPOWER**

**HAWKE**  
International

3940 Dr. Martin Luther King Drive  
St. Louis, MO 63113

P/N KIL00901308 FORM NO. K0569F ECO-3-011-12  
R04/2012 FORMULE NO. K0569F R04/2012