
SPECIFICATION AND INSTALLATION GUIDE

FCR1 Field Cut Riser System

For Use with Grease Interceptors Models GB1. GB2 and GB3





Contents

Specifications	
Getting to Know the FCR1	
Installation	

Riser Height Needed	Risers Required
2-1/8" - 12"	FCR1
>12" - 25"	FCR1 (x2)

Notes

- 1. Unit weight: 10 lbs.
- 2. Risers not designed to hold water

Engineer Specification Guide:

Field-cut adjustable riser system for use with GB1, GB2 and GB3.


Installation Note

Minimum install height: 2-1/8". Maximum install height: 12". Riser system may be stacked no more than two units high to a maximum of 25" extension. Access to internal components will not be compromised.



MODEL NUMBER: FCR1	DESCRIPTION: 12" Field Cur Riser System		
PART #: 8010-005-01	DATE: 03/10/2025	REV:	ECO:

GETTING TO KNOW THE FCR1



- 1. Cover Ring
- 2. Cover Ring Gasket
- 3. Riser Mounting Bolts

- 4. Riser Body
- 5. Riser Mounting Flange
- 6. Riser Body Gasket

FCR1 Installation Guide page 2 of 4


INSTALLATION

Special Precautions




DO NOT AIR TEST UNIT OR RISER SYSTEM!

Doing so may result in property damage, personal injury or death.






Do not add any form of lubricant to riser tube during installation.



Tools You Will Need








Tape Measure Flat Head Screwdriver Reciprocating Saw, Circular Saw or Jigsaw

1 Determine number of risers needed




For the interceptor to be safely and properly maintained, dimension A cannot exceed 25" (or two FCR1 risers stacked).



2 OPTIONAL: Install Flow Control Extension Handle


For easy flow control removal, 1-1/2" PVC SCH. 40 pipe may be cut to length and attached to top of flow control cartridge using PVC primer/cement.





FCR1 Installation Guide page 3 of 4

3 Mark and cut top-most riser











Push cover ring onto riser body until it stops (about 1").

Ensure cover ring gasket is positioned as shown.

Place riser on interceptor, aligning bolt holes.











Measure "X" with tape measure.


Remove cover ring from riser assembly and mark "X" with supplied grease pencil.


Cut "X" from top of riser and discard.

4 Fasten riser to interceptor










Ensure cover ring gasket is positioned as shown.



Place riser on interceptor, aligning bolt holes and fasten securely with mounting bolts.

5 Prepare for backfill

Resume "Buried Installation" instructions for applicable unit (GB1, GB2 or GB3)

FCR1 Installation Guide page 4 of 4