



SNAP-IN TUBELESS TIRE VALVES

Instructions

1. Remove valve core and deflate tire.
2. Break bead of tire and remove from rim.
3. Remove existing valve stem from rim.
4. Clean rim hole of dust and debris.
5. Install new stem from inside of rim.
6. Reinstall tire and inflate to manufacturer's recommended pressure.
7. Replace valve cap.

NOTE: Maximum recommended pressure is 60 PSI.

WARNING: This product contains chemicals, including lead, known to the State of California to cause cancer, birth defects or other reproductive harm. *Wash hands after handling.*

VÁLVULAS PARA NEUMÁTICOS SIN CÁMARA

Instrucciones

1. Retire el centro de la válvula y desinfe el neumático.
2. Rompa el talón del neumático y sáquelo del aro.
3. Retire del aro el vástago de la válvula existente.
4. Limpie el polvo y la suciedad del orificio del aro.
5. Instale el nuevo vástago desde el interior del aro.
6. Reinstale el neumático e ínflalo según la presión recomendada por el fabricante.
7. Vuelva a poner la tapa de la válvula.

NOTA: La presión máxima recomendada es de 60 PSI.

ADVERTENCIA: Este producto contiene sustancias químicas, incluyendo el plomo, que según el Estado de California causan cáncer, defectos congénitos u otro daño al sistema reproductor.

Lávese las manos después de usar el producto.