



## CHROME VALVE EXTENSIONS

### Instructions

1. Remove existing valve cap.
2. Check tire pressure and adjust to manufacturer's recommended pressure.
3. Install valve extension.
4. Air may now be checked and inflated without removal of extension.

Proper tire pressure improves gas mileage, handling, braking and durability.

**WARNING:** This product contains chemicals, including lead, known to the State of California to cause cancer, birth defects or other reproductive harm. *Wash hands after handling.*

## EXTENSIONES DE CROMO PARA VÁLVULAS

### Instrucciones

1. Quite la tapa de la válvula existente.
2. Revise la presión del neumático y ajústela según las recomendaciones del fabricante.
3. Instale la extensión de la válvula.
4. El aire se puede revisar e inflar sin antes retirar la extensión.

La correcta presión del neumático ahorra gasolina y mejora la maniobrabilidad, la acción de los frenos y la durabilidad.

**ADVERTENCIA:** Este producto contiene sustancias químicas, incluyendo el plomo, que según el Estado de California causan cáncer, defectos congénitos u otro daño al sistema reproductor. *Lávese las manos después de usar el producto.*