

# QUEKILI BONDEROOF LINE BONDEROOF





### BLACK AND WHITE



### INSTANT SELF-ADHESIVE ROOF REPAIR

#### **Permanently Repairs:**

EPDM, TPO, Hypalon<sup>®</sup>, Metal, Modified Asphalt, Vinyl, Fiberglass, Aged & Rigid PVC, OSB, Rigid Extruded Polystyrene, Wood, and Tile.

# Can even be applied to most materials when damp!

#### 15 year limited warranty

QUICK ROOF ULTRABOND IS GUARANTEED NOT TO CRACK, HARDEN, OR SHRINK. IN ADDITION TO INSTANTLY STOPING LEAKS AND PERMANENTLY REPAIRING MOST ROOFING MATERIALS, QR ULTRABOND WILL REPAIR SKYLIGHTS, GUTTERS, FLASHINGS, RV's & MOBILE HOMES, TRUCKS & TRAILERS, GARDEN SHEDS, POND LINERS, TARPS, AND WILL EVEN STICK TO BRICK AND CONCRETE.

#### **QUICK ROOF ULTRA BOND BLACK**







6"x25'

4"x25

4"×10'

#### **QUICK ROOF ULTRA BOND WHITE**







6"x25"

4"×25

4"×10" Part#UBW410

#### DIRECTIONS FOR THE USE OF QUICK ROOF ULTRA BOND

Steel-Loc Adhesive's remarkable bonding properties are the result of its proprietary blending of unique synthetic co-polymers and butyl rubber. It can be installed to temperatures as low as 25°F without the need for primer, and keeps on sticking from -70°F to 200°F. For colder application temperatures, down to -25°F, use QUICK ROOF SEAM PRIME before application.

QUICK ROOF ULTRABOND IS GUARANTEED NOT TO CRACK, HARDEN, OR SHRINK.

IN ADDITION TO INSTANTLY STOPING LEAKS AND PER-MANENTLY REPAIRING MOST ROOFING MATERIALS. QR ULTRABOND WILL REPAIR SKYLIGHTS, GUTTERS, FLASHINGS, RV's & MOBILE HOMES, TRUCKS & TRAIL-ERS, GARDEN SHEDS, POND LINERS, TARPS, AND WILL EVEN STICK TO BRICK AND CONCRETE.

SURFACE PREPARATION: The repair area should be clean and free of dirt, dust, oxidation, and any oily residue. For maximum adhesion and ease of application, a dry surface is preferred. However, QR ULTRABOND can be applied to most non-porous surfaces when wet.

**DIRECTIONS FOR USE:** For smaller repairs, with backing paper attached, unroll QR ULTRABOND over repair area. Use a sharp scissors or knife to cut to the correct length. Peel off EASY RELEASE backing paper and firmly press in place. For larger repair areas begin by removing 6 to 12 inches of EASY RELEASE backing paper and press QR UL-TRABOND In place. Slowly and carefully continue to unroll the roll, continuing to remove the release paper and pressing in place as you go. To maximize adhesion, go over the repair

area using a small hand roller while applying moderate pressure, taking care to remove any pockets of trapped air.

When applying in wet conditions, apply a small test patch first to assure proper adhesion. Use maximum pressure to squeeze moisture out from between QR ULTRABOND and the surface to be repaired. Allowing excess moisture to remain will undermine the adhesive bond.

#### **WARNINGS:**

- Be sure repair area is structurally sound and will support the weight of the installer.
- Do not install QR ULTRABOND over plasticized PVC.
- Do not install QR ULTRABOND over fresh silicone caulk. If installing over cured silicone adhesion may be compromised.
- Do not install QR ULTRABOND on frost-covered surfaces.
- QR ULTRABOND is not intended to repair boats or other marine craft below the waterline

LIMITED WARRANTY: Cofair warrants this product to be of merchantable quality when used and/or applied in accordance with instructions hereon. Cofair does not warrant this product for any other purpose or use other than for the general purpose for which it was intended. Liability under this warranty is limited to the replacement of defective product as purchased. THIS LIMITED WARRANTY IS ISSUED IN LIEU OF ALL OTHER EXPRESSED AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF FITNESS, AND EXPRESSLY EXCLUDES LIABILITY FOR CON-SEQUENTIAL DAMAGES.

Hypalon® is the registered trademark of its respective company which is not affiliated in any way with Cofair Products, Inc





Skokie, IL 60076 Phone: 800-333-6700