

SMART SPRAY™

Universal Pull Down Spray Head Abaisser la tête de pulvérisation universel

INSTRUCTIONS

1. Shut water off to faucet.
2. Unscrew old Pull Down Head from your faucet.
3. Determine which adapter properly fits your hose.
Note: There are specific hoses that fit directly into the head without an adapter.
4. Screw adapter into hose (hand tighten). If your faucet is Pfister® or Glacier Bay® then the SMART SPRAY will fit directly onto the hose without an adapter.
5. Screw SMART SPRAY into the adapter or hose (hand tighten).
6. Turn water to faucet back on.
7. Check for leaks.

INSTRUCTIONS

1. Couper l'alimentation d'eau aux robinets.
2. Dévisser l'ancienne tête escamotable du robinet.
3. Déterminer quel adaptateur est approprié pour le tuyau.
Remarque : Il y a des tuyaux qui s'adaptent directement à la tête sans nécessiter d'adaptateur.
4. Visser l'adaptateur au tuyau (serrer à la main). Si votre robinet est de la marque Pfister® ou Glacier Bay®, alors l'adaptateur intelligent SMART SPRAY s'adaptera directement sur le tuyau sans nécessiter d'adaptateur.
5. Visser le SMART SPRAY sur l'adaptateur ou le tuyau (serrer à la main).
6. Remettre l'alimentation d'eau aux robinets.
7. Vérifier toute trace de fuite.

