


CONNECTS 1/4" COPPER TO COPPER, COPPER TO POLY, OR POLY TO POLY



CAUTION: Turn off electricity at circuit breaker before working on evaporative cooler.

***NOT FOR USE WITH
POTABLE WATER LINES***

Copper Tubing: 1. Cut the end of the tube square to insure proper fit. 2. Place nut and sleeve onto copper tube. 3. Tighten nut with a wrench.

Poly Tubing: 1. Cut the end of the tube square to insure proper fit. 2. Place nut and sleeve onto poly tube. 3. Insert poly tube adapter into end of tube. 4. Tighten nut with a wrench.

⚠ WARNING: Cancer and Reproductive Harm
- www.P65Warnings.ca.gov .ca.gov.

PN 9329 Form 993513-0218



0 26529 93290 5

www.dialmfg.com Made in China

© Copyright 2018 Dial Mfg., Inc. Phoenix, AZ