



# INSTRUCTIONS FOR USE

## INSTRUCCIONES DE USO

### POLY FOAM INSULATION



#### Pre-Slit Design

##### Preparation:

Install when the temperature is between 40°- 90°F (5°-32°C).

##### Installation:

1. Cut tube to needed length with sharp blade. Open tube on pre-slit line and slip over the pipe.
2. For bends, cut wedge-shaped sections from unslit side of tube.
3. For elbows or "T" connections, make miter cuts on pre-slit side of tube.
4. Open tube on pre-slit line, slip over pipe and butt together, then seal all joints
5. Adhering seams is recommended.



### ESPUMA AISLANTE DE POLIURETANO



#### Diseño Pre-rajado

##### Preparación:

Instále cuando las temperaturas estén alrededor de 40°- 90°F (5°-32°C).

##### Instalación:

1. Corte el tubo a la longitud apropiada con una navaja afilada. Abra el tubo en la linea pre-hendida y deslícelo sobre la tubería.
2. Para tuberías curvas, corte secciones en forma de prisma triangular en el lado no está pre-hendido del tubo.
3. Para codos o conexiones en "T", haga cortes en escuadra sobre el lado pre-hendido.
4. Abra el tubo en la línea pre-hendida, deslícelo sobre la tubería y empalme juntos. Selle después todas las uniones.
5. Se recomienda sellar las uniones.



Follow Us @FrostKing  
or [www.frostking.com](http://www.frostking.com)



Thermwell Products Co., Inc.  
Mahwah NJ 07430 | Sparks NV 89431

Need help or information  
about any Frost King product?  
**Call 1-877-FROST 20**  
37678

For videos, instructions, hints and tips  
visit [www.frostking.com/instructions](http://www.frostking.com/instructions)