

HENRY®



336

Improves adhesion
on dry, dusty and
porous substrates

Excellent Primer

Improves adhesion to substrates

Add to HENRY 331

Improves bond to substrates

1-Year Limited Warranty

Sizes Available

1 gallon, 4 gallon

THE PROFESSIONAL'S FORMULA FOR SUCCESS™

HENRY® 336

HENRY 336 is The Professional's Formula For Success when used with HENRY 331 Super Patch.

SUBSTRATE	PRIMERS & ADDITIVES	
	HENRY 336	HENRY 546
	FLOOR PRIMER & ADDITIVE	FEATHER EDGE ADDITIVE
	As An Additive w/HENRY 331	As An Additive w/HENRY 545 & 547
Commercial Applications		OPTIONAL
Residential Applications	OPTIONAL	OPTIONAL
Patch holes and voids in wood	OPTIONAL	OPTIONAL
Skim-coat wood underlayments		REQUIRED
Underlayment joints		REQUIRED
Patch concrete on or above grade only	OPTIONAL	OPTIONAL
Patch concrete on all grade levels		OPTIONAL
Ceramic, terrazzo and marble		OPTIONAL
Polymeric poured floor		OPTIONAL
Steel		REQUIRED
Stainless Steel		REQUIRED
Lead		REQUIRED
Embossing Leveler		
Residential floor with stain-resistant wear layer		REQUIRED
Residential floor without stain-resistant wear layer		REQUIRED

SUBSTRATES:

HENRY 336 Floor Primer and Latex Liquid Additive will bond as a primer to the substrates listed. Specific recommendations should come from the flooring manufacturer:

- Concrete
- Poured-in-place gypsum subfloors
- Wood and wood underlayments
- Radiant heated subfloors where the surface temperature does not exceed 85°F (29°C)
- Wall surfaces such as wood, plaster, drywall, and masonry

INSTALLATION TIPS:

- Condition the area to be installed, adhesive, primer and flooring to 65°F (18°C) or above for 48 hours before, during, and for 48 hours after installation.
- Subfloor must be smooth, sound, dry, clean, and free of dirt, wax, polish, paint, and all other foreign matter which may interfere with a good bond including curing agents and sealers. Concrete must be dry and free of excess alkali.
- Apply with a short nap paint roller or a coarse fiber brush. Do not allow puddles to form or remain on the surface.
- Use full strength.
- Allow to dry completely, approximately 30 minutes or more.
- Clean tools with water before material dries.

HENRY

The W. W. Henry Company
 400 Ardex Park Drive
 Aliquippa, PA 15001
 Technical Support: 1-800-232-4832
 Internet: wwhenry.com

IPD-240-899

HENRY Commitment

HENRY is committed to helping you get the best results in professionally installed floors. Sixty years of experience combined with our relationships with the leading resilient, wood and carpet manufacturers ensure that you receive the products and the support you need to complete the job successfully and profitably.

THE PROFESSIONAL'S FORMULA FOR SUCCESS™