



M8530

# POP-UP VANITY DRAIN EGOUT DE COIFFEUSE MOBILE DESAGÜE DE TOCADOR A RESORTE



1. Remove flange ① and gasket ② from tailpiece ③.
2. Place nut and washer onto tailpiece ③ and lower into drain.
3. Apply bead of plumber's putty around rim of hole in sink.
4. Insert flange ① into hole and place gasket ②, beveled side up onto flange.
5. Thread flange ① into tailpiece ③.
6. Turn on water. Check for leaks.

1. Quitter la flasque ① et le support ② de la queue ③.
2. Placer l'écrou et la rondelle sur la queue ③ et les descendre dans l'égout.
3. Appliquer un ruban de mastique de plombier autour du trou dans le lavabo.
4. Insérer la flasque ① dans le trou et placer le support ②, avec le cté biseauté en haut dans la flasque.
5. Visser la flasque ① dans la queue ③.
6. Faire couler l'eau. Vérifier l'absence de fuites.

1. Quite el tubo con reborde ① y el empaque ② de la coleta ③.
2. Coloque la tuerca y la arandela de empaque en la coleta ③ y deslice la coleta en el tubo del desagüe.
3. Coloque masilla de plomero en el reborde del agujero del lavabo.
4. Coloque el tubo con reborde ① dentro del agujero y coloque el empaque ②, con el lado biselado hacia arriba en el tubo con reborde ①.
5. Enrosque el tubo con reborde ① en la coleta ③.
6. Abra el paso del agua. Revise si hay fugas.

CONTENTS: 1 Drain Assembly

CONTENTU: 1 Bâti de l'Égout

CONTENIDO: 1 Conjunto de drenaje

