

IMPORTANT INSTALLATION INSTRUCTIONS

Before turning on water:

1. Load batteries
2. Attach valves to timer and manifold
3. Allow the timer a few minutes to complete the automatic setup

INSTRUCCIONES DE INSTALACIÓN IMPORTANTES

Antes de dejar correr el agua:

1. *Cargue las baterías.*
2. *Conecte las válvulas al temporizador y al tubo colector.*
3. *Dé algunos minutos al temporizador para que complete la configuración automática.*

PN 27752-36 rA



F 801 295 9820
F 801 951 5815
www.fluid-studio.net
1065 South 500 West
Bountiful, Utah 84010

PROOF NO: 3

DATE: 09.14.09

DES: SH **SPCK:** SH

JOB NO:

CLIENT: Orbit

SKU: 27752

UPC: NA

FILE NAME: 27752-36 rA.indd

SOFTWARE: InDesign CS3

DIMENSIONS:

FLAT: W: 3.0" **H:** 2.0"

FINISHED: W: 3.0" **D:** " **H:** 2.0"

COLORS



Registration



die color
non printing



color
non printing



CMYK



PMS
Black



PMS
???



PMS
????

ADDITIONAL INSTRUCTIONS:

- Font sizes cannot be smaller than 7 pt.
- Proofing Code: LB485772

Printers are responsible for meeting print production requirements. Any changes must be approved by the client and Fluid Studio.

PRINTED PIECE MUST MEET DESIGNATED SPECIFICATIONS ON THIS FORM.

© 2007 Fluid Studio. This work is the property of Fluid Studio, and cannot be used, reproduced or distributed in any way without their express permission.