

TRIM-TEX

DRYWALL PRODUCTS

Tear Away L Bead

Used to finish the rough edge of the drywall. Features a tear off strip that acts as a guide for the taping knife as well as a protective mask for mudding.

Installation Instructions

- Step 1:** Measure and cut the bead to length. Dry fit to test proper cut.
- Step 2:** Spray the bead and corner with 1 coat each of Trim-Tex 847 Spray Adhesive and position the bead into place.
- Step 3:** Once in position, pressure the leg using a Trim-Tex installation tool or the handle of your taping knife.
- Step 4:** Staple the mud leg into place every 6"-8" with ½" staples.
- Step 5:** Mud as usual. Be sure to use All-Purpose or Multi-Purpose Compound. Add Mud-Max to your drywall compound for extra durability.
- Step 6:** Remove the tear-off strip after mudding but before sanding. Prime and paint as usual.

