

1. Turn the tubes in opposite directions to make the rod longer or shorter.
2. Extend the tubes to 1 1/2 inches wider than the wall opening.
3. Put one end in place on the wall; compress the rod and put the other end into place.

1. Turn the tubes in opposite directions to make the rod longer or shorter.

2. Extend the tubes to *approximately* 2 inches wider than the wall opening.

3. Put one end in place on the wall; compress the rod and put the other end into place.

1. Gire los tubos en direcciones opuestas para hacer el tubo más largo o más corto.

2. Extienda los tubos *aproximadamente* 2 pulgadas más ancho que la apertura de la pared.

3. Coloque un extremo en su lugar en la pared, comprima el tubo y coloque el otro extremo en su lugar.

1. Tournez les tubes en sens inverse pour allonger ou raccourcir la tringle.

2. Étirez les tubes *environ* 5 cm (2 po) de plus que la largeur de l'ouverture.

3. Placez une extrémité à l'endroit désiré sur le mur ; compressez la tringle pour positionner l'autre extrémité du côté opposé.