



## INSTALLATION GUIDE

### AP-5200 & AP-6200

**TIP:** For an optimal use, one Access Panel must be placed over the downspout and at the other end of the eavestrough.



1. Insert the front of the Access Panel inside the front of the eavestrough.
2. Insert the back of the Access Panel on the back of the eavestrough.
3. Make sure that each Access Panel overlaps perfectly with the T-Rex (the Access Panel must be over the T-Rex).
4. Using an end cap crimping tool, pinch the back of the Access Panel and the eavestrough at both ends of the Access Panel.
5. Place the Access Panel inside the end cap in order to prevent water from overflowing.
6. Insert the back of the eavestrough under the drip edge (flashing).
7. Screw the back of the Access Panel into the fascia board at each end with the self-sealing screws. **A.**
8. Install the sliding panel above the opening with one ½" screw on each side. The screws need to be placed near the back of the gutter. **B.**

