


3.0 Cassette Installation

- 3.1 Insert the MTP* cassette through the mounting bracket and secure it by locking the plastic rivets.
- 3.2 Feed one end of the MTP* patch cord through a desired grommet location and connect it to the rear port of the cassette.
- 3.3 Route and connect the free end of the MTP* patch cord to the appropriate equipment.



* MTP is a registered trademark of US Conec Ltd.

For Instructions in Local Languages
and Technical Support:
www.panduit.com/resources/install_maintain.asp

PANDUIT
www.panduit.com

E-mail:
techsupport@panduit.com
Phone:
866-405-6654