

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK,
OR INJURY TO PERSONS

IMPORTANT SAFETY INSTRUCTIONS

- WARNING -** When using electric appliances, basic precautions should always be followed, including the following:
- Read all the instructions before using the appliance.
 - To reduce the risk of injury, close supervision is necessary when an appliance is used near children.
 - Do not use outdoors.
 - To reduce the risk of electric shock, do not put flashlight in water or other liquid. Do not place or store appliance where it can fall or be pulled into a tub or sink.
 - No LED replacement is needed
 - Battery pack type Nickel Metal Hydride 2.4V 330mah Rechargeable Button Cell


SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS
HOUSEHOLD USE ONLY

1. Turn off the flashlight.
2. Flip out the wall plug and plug the flashlight into the household 120V socket.
3. To ensure maximum battery performance, a new rechargeable flashlight or a rechargeable flashlight that has not been used for several months should be charged for at least 24 hours before use.
4. After charging, simply remove flashlight from the wall socket, flip the plug back into the housing. Use the push button switch to operate the flashlight.
5. Switch to “FLASH” during charging can give emergency light when input power fails.
6. Fully charged flashlight may be stored for 12 months before recharging.
7. Conservative charging system is being used to protect this flashlight from being left on continuous charging.
8. Do not replace batteries with flashlight plugged into duplex receptacle.
9. Make sure battery cover is secure before plugging into duplex receptable.
10. Do not operate flashlight without battery cover secured.

USER MAINTENANCE INSTRUCTIONS

This flashlight is designed to out last the service life of the batteries.
Below is the battery replacement instruction:-



INSTRUCCIONES PARA EVITAR INCENDIOS, DESCARGAS ELÉCTRICAS
O LESIONES A PERSONAS

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

- ADVERTENCIA -** Cuando se usan aparatos eléctricos, siempre se deben seguir las medidas básicas de seguridad, incluidas las siguientes:
- Lea todas las instrucciones antes de usar el aparato eléctrico.
 - Para reducir el riesgo de lesiones, es necesario contar con supervisión cuando se use un aparato eléctrico cerca de niños.
 - No la use en exteriores.
- Para reducir el riesgo de descargas eléctricas, no coloque la lámpara en agua ni en otro tipo de líquido. No coloque ni guarde la lámpara donde pueda caerse o ser arrastrada dentro de una tina, un lavabo o un fregadero
- No es necesario reemplazar el diodo LED.
 - Paquete de pilas de níquel e hidruro metálico de 2.4 V y 330 mAh, con celda de botón recargable

GUARDE ESTAS INSTRUCCIONES

INSTRUCCIONES DE OPERACIÓN
SÓLO PARA USO CASERO

1. Apague la lámpara.
2. Abra el enchufe para pared y conecte la lámpara en el receptáculo de 120 V de la vivienda.
3. Para garantizar el máximo desempeño del paquete de pilas, si se trata de una lámpara recargable nueva o una lámpara recargable que no se ha utilizado durante varios meses, debe dejarse cargando por lo menos 24 horas antes de usarla.
4. Después de cargarla, simplemente retire la lámpara del tomacorriente de pared y vuelva a colocar el enchufe dentro del receptáculo. Utilice el interruptor de botón para accionar la lámpara.
5. Si coloca el interruptor en la posición "FLASH" durante la carga, se activará la función de luz de emergencia en caso de corte de energía.
6. La lámpara totalmente cargada puede guardarse 12 meses antes de recargarla.
7. Se utiliza un sistema de carga conservador para proteger la lámpara y que no se quede cargando continuamente.
8. No cambie las pilas con la lámpara conectada en un tomacorriente doble.
9. Asegúrese de que la tapa de las pilas esté firme antes de conectar la lámpara en un tomacorriente doble.
10. No haga funcionar la lámpara sin tener asegurada la tapa de las pilas.

INSTRUCCIONES DE MANTENIMIENTO
PARA EL USUARIO

Esta lámpara está diseñada para durar más que la vida útil de la pila.
A continuación, encontrará las instrucciones:

