

Entenmann's® Bakeware

Product Catalog



458 East 101st Street, Brooklyn, NY 11236
 T: (718) 272-4582 • F: (718) 272-4594

www.euro-ware.com

New York • Chicago • Philadelphia • Michigan • Miami

Entenmann's® Classic



Item# ENT19001
Classic Square Pan
10"x8"x2.4"
 Case Pack: 12



Item# ENT19002
Classic Round Pan
9.5"x1.5"
 Case Pack: 12



Item# ENT19003
Classic Pie Pan
9.5"x1"
 Case Pack: 12



Item# ENT19004
Classic Loaf Pan
11.6"x5"x2.5"
 Case Pack: 12



Item# ENT19008
Classic Baking Pan
16"x10"x2"
 Case Pack: 12



Classic Cookie Sheet
Item# ENT19005 - S
15"x10"x.5"
Item# ENT19006 - M
17"x11.75"x.5"
Item# ENT19007- L
19"x12"x.5"
 Case Pack: 12



Item# ENT19016
Classic Bundtform Pan
10"x3"
 Case Pack: 12



Item# ENT19017
Classic Angel Food Pan
10"x4"
 Case Pack: 12



Item# ENT19010
Classic 6 Cup Muffin Pan
Case Pack: 12



Item# ENT19011
Classic 6 Cup Jumbo Muffin Pan
Case Pack: 12



Item# ENT19012
Classic 12 Cup Muffin Pan
Case Pack: 12



Item# ENT19020
Classic 12 Cup Mini Donut Pan
Case Pack: 12



Item# ENT19013
Classic 24 Cup Mini Muffin Pan
Case Pack: 12



Item# ENT19015
Classic 8 Cup Mini Loaf/Brownie Pan
Case Pack: 12



Item# ENT19021
Classic 6 Cup Muffin Top Pan
Case Pack: 12



Item# ENT19022
Classic 6 Cup Donut Pan
Case Pack: 12



Item# ENT19031
Cake Pop Set
 Case Pack: 8



Item# ENT49020
Cupcake & Cookie Decorating Set
 Case Pack: 12



Item# ENT49004
Classic Brownie Maker
15"x8"x2.6"
 Case Pack: 6



Item# ENT49008
Two Tone Cupcake Set
 Case Pack: 8



Item# ENT49009
Half & Half 12 Cupcake Pan
 Case Pack: 8



Item# ENT49010
Push Pop Cake Set
 Case Pack: 8



Item# ENT49011
Classic 3 PC. Cookie Sheet Set
S - 15"x10.7"
M - 17"x11.5"
L - 19"x13.2"
 Case Pack: 8



Item# ENT49013
Classic 4 PC. Baking Set
Set Includes:
1 - 9"x1.5" Round Pan
1 - 9"x4.5"x2" Loaf Pan
1 - 13"x9"x2" Bake Pan w/Cover
 Case Pack: 6



Item# ENT49002
Classic 3 PC. Springform Set
Set Includes:
S - 9.5"x2.5"
M - 10.2"x2.5"
L - 11"x2.5"
 Case Pack: 6



Item# ENT49005
Classic 5 PC. Bakeware Set
Set Includes:
2 - 9" Round Pan
1 - 15"x10" Baking Sheet
1 - 13"x9" Bake Pan
1 - 11"x7" Bake Pan
 Case Pack: 6



Item# ENT49006
Classic 3 PC. Bakeware Set
Set Includes:
1 - 11.6"x5"x2.5" Loaf Pan
1 - 17"x11.75"x.5" Cookie Sheet
1 - 6 Cup Muffin Pan
 Case Pack: 6



Item# ENT49003
Classic 5 PC. Baking Set
Set Includes:
1 - 14.4"x9.8"x2" Bake Pan
1 - 10"x5"x2.5" Loaf Pan
1 - 14.6"x10.2"x.6" Cookie Sheet
1 - 6 Cup Muffin Pan
1 - Spatula
 Case Pack: 4

Entenmann's Ultimate



Item# ENT29001
Ultimate Square Pan
9"x9"x1.5"
 Case Pack: 12



Item# ENT29002
Ultimate Round Pan
8.5"x1.5"
 Case Pack: 12



Item# ENT29003
Ultimate Pie Pan
12"x1.5"
 Case Pack: 12



Item# ENT29004
Ultimate Loaf Pan
11.6"x5"x2.5"
 Case Pack: 12



Ultimate Cookie Sheet
Item# ENT29005 - S
16.5"x10"x.5"
Item# ENT29006 - M
18.5"x11.2"x.75"
 Case Pack: 12



Item# ENT29008
Ultimate Baking Pan
16.6"x10"x1.2"
 Case Pack: 12



Item# ENT29010
Ultimate 6 Cup Muffin Pan
 Case Pack: 12

Entenmann's Ultimate



Item# ENT29012
Ultimate 12 Cup Muffin Pan
 Case Pack: 12



Item# ENT29013
Ultimate 24 Cup Mini Muffin Pan
 Case Pack: 12



Item# ENT29014
Ultimate Jumbo Cupcake Pan
15.4"x8"x3.7"
 Case Pack: 12



Item# ENT29016
Ultimate Bundform Pan
9"x4"
 Case Pack: 12

Entenmann's[®] BAKERY GRADE



Item# ENT29301
Bakery Grade Square Pan
9.5"x9.5"x2"
 Case Pack: 6



Item# ENT29302
Bakery Grade Round Pan
9"x1.5"
 Case Pack: 6



Item# ENT29304
Bakery Grade Loaf Pan
9"x5"x2.5"
 Case Pack: 6



Item# ENT29305
Bakery Grade Small
Cookie Sheet
13"x9"x1"
 Case Pack: 6



Item# ENT29306
Bakery Grade Large
Cookie Sheet
15"x10"x1"
 Case Pack: 6



Item# ENT29308
Bakery Grade Baking Pan
13"x9"x2.5"
 Case Pack: 6



Item# ENT29310
Bakery Grade 6 Cup
Jumbo Muffin Pan
 Case Pack: 6



Item# ENT29312
Bakery Grade 12 Cup
Muffin Pan
 Case Pack: 6



Item# ENT29313
Bakery Grade 12 Cup
Mini Muffin Pan
 Case Pack: 6

Entenmann's Minis



Item# ENT39002
Kids 7 PC. Mini Bakeware Set
Set Includes:

- 1 - 4.8"x1.2" Round Pan
- 1 - 11"x7"x1.2" Baking Pan
- 1 - Wooden Pastry Brush
- 2 - Plastic Cookie Cutters
- 1 - Measuring Spoon Set
- 1 - Whisk

Case Pack: 12



Item# ENT39003
Kids 10 PC. Mini Baking Set
Set Includes:

- 1 - 9.5"x7"x.75" Baking Tray
- 1 - Wooden Rolling Pin
- 8 - Assorted Cookie Cutters

Case Pack: 12



Item# ENT39004
Kids 3 PC. Mini Bakeware Set
Set Includes:

- 1 - 5.4"x3"x1.2" Loaf Pan
- 1 - 4.5"x1.75" Springform Pan
- 1 - Wooden Rolling Pin

Case Pack: 12



Item# ENT39000
Kids Mini Bakeware
in Display

Case Pack: 72



Item# ENT39005
Kids Bake Pan
w/Animal Cookie Cutters
1 - 11"x11.5"x.5" Baking Tray
14 - Plastic Cookie Cutters

Case Pack: 12



Item# ENT39010
Kids 8 PC. Mini Baking Set
Set Includes:
 1 - 8"x1.5" Round Pan
 1 - Spatula
 4 - Assorted Cookie Cutters
 1 - Measuring Spoon Set
 1 - Whisk
 Case Pack: 12



Item# ENT39011
Kids 8 PC. Mini Baking Set
Set Includes:
 1 - 8.5"x8.5"x1.5" Baking Pan
 1 - Spatula
 4 - Assorted Cookie Cutters
 1 - Measuring Spoon Set
 1 - Whisk
 Case Pack: 12



Item# ENT39012
Kids 6 PC. Mini Baking Set
Set Includes:
 1 - 12 Cup Muffin Pan
 1 - 5.4"x3"x1.2" Mini Loaf Pan
 1 - Wooden Pastry Brush
 2 - Plastic Cookie Cutters
 1 - Whisk
 Case Pack: 12



Item# ENT39013
Kids 16 PC. Mini Baking Set
Set Includes:
 1 - Mixing Bowl
 1 - 8"x1.5" Round Pan
 10 - Assorted Plastic Cookie Cutters
 1 - Measuring Cup
 1 - Measuring Spoon Set
 1 - Spatula
 1 - Whisk
 Case Pack: 6



Item# ENT39014
Kids 7 PC. Mini Baking Set
Set Includes:
 1 - 11"x7"x1.2" Cookie Sheet
 1 - 4.8"x1.2" Round Pan
 1 - Whisk
 1 - Wooden Rolling Pin
 3 - Assorted Cookie Cutters
 Case Pack: 12

Entenmann's On the Go



Item# ENT19033
Classic Baking Pan
w/Cover
Pan Dimensions:
16"x10"x2"
Case Pack: 8



Item# ENT19032
Classic 12 Cup Muffin
Pan w/Cover
Case Pack: 8




Item# ENT29017
Ultimate Bundtform Pan w/Cover
Pan Dimensions: 9.6"x4"
Case Pack: 4



Item# ENT29018
Ultimate Spring Form w/Carrier
Pan Dimensions: 10.2"x2.7"
Case Pack: 4



Item# ENT19028
Classic Covered Bake Pan
9"x13" Baking Pan
Case Pack: 8



Item# ENT29019
Ultimate 24 Cup
Muffin Carrier & Pan
Set Includes:
1 - 12 Cup Muffin Pan
1 - 12 Cup Plastic Muffin Tray
Case Pack: 4



Item# ENT29110
24 Ct Cupcake Freshkeeper/Carrier
Set Includes:
1 - 12 Cup Muffin Pan
1 - 12 Cup Plastic
Muffin Tray
Case Pack: 4



Item# ENT29114
24 Ct Cupcake Freshkeeper/Carrier
Set Includes:
1 - 12 Cup Muffin Pan
1 - 12 Cup Plastic Muffin Tray
Case Pack: 2



Item# ENT29116
12 Ct Cupcake Carrier
w/ Cupcake Stand
Set Includes:
1 - 12 Cup Muffin Pan
1 - 3 Tier Stand
Case Pack: 4



Item# ENT19035
12 Cupcake & Baking Pan
Carrier Set
Set Includes:
1 - 12 Cup Muffin Pan
1 - 9"x13" Baking Pan
Case Pack: 6





Item# ENT69001
Classic Bakeware in Display
 Case Pack: 48



Item# ENT69005
Kids Baking Set Display
 Case Pack: 32(3 Styles)



Item# ENT69010
Brownie Maker Display
 Case Pack: 12



Item# ENT69015
Jumbo Cupcake Display
 Case Pack: 15



Item# ENT69016
Jumbo Cupcake/Donut Display
 Case Pack: 21
 (9-Cupcake, 12 Donut)



Item# ENT69030
Christmas Display
 Case Pack: 24(3 Styles)



Item# ENT69021
Classic 12 Cup Muffin Pan w/Cover/Classic Baking Pan w/Cover Display
 Case Pack: 18 Assorted

EURO-WARE™, Inc.

www.entenmannsbakeware.com

Corporate Office & Warehouse

**458 East 101st Street
Brooklyn, NY 11236
Phone: 718-272-4582
Fax: 718-272-4594**

Manhattan Showroom

**(by appointment)
230 Fifth Avenue, Suite 508
New York, NY 10001**

Chicago Showroom

**(by appointment)
9555 Foster Avenue
Suite# 340
Schiller Park, IL 60176**

Philadelphia Showroom

**(by appointment)
Mid-Atlantic Merchandise Mart
12300 McNulty Road
Philadelphia, PA 19154**

Miami Showroom

**20600 NW 47th Ave
Miami Gardens, FL 33055**