


Figure #3

NET ASSEMBLY



Step Assembly Instructions

1. The net has been designed with red tabs to identify the top corners and blue tabs to identify the bottom corners. Follow the numbered sequence to attach the net.
2. Using the self-stick closure strips, tie the top corners first which are identified by the two red tabs. Refer to ① & ②.
3. Using the self-stick closure strips, tie the front bottom corners which are identified by the two blue tabs. Refer to ③ & ④.
4. Stretch the net and using the self-stick closure strips tie the back bottom corners. Refer to ⑤ & ⑥.
5. Attach self-stick closure strips as follows:
4 on the top ⑦, 3 on the sides ⑧, 2 on the base ⑨, and 4 on the base ⑩ as shown.

Franklin Sports Inc.
17 Campanelli Parkway
Stoughton, MA. 02072
Made in China

For replacement parts call
1-800-225-8647

Franklin®


NO. 5660

SOCCKER GOAL

SIZE: 6'Wide x 4'High x 3'Deep

BEFORE ASSEMBLY:

- Work on a smooth, flat surface.
- Lay out all components so they are in easy reach.
- Read assembly instructions completely to familiarize yourself with the components.



This goal is designed to provide many hours of enjoyment if properly assembled and used only for the purpose intended.

⚠ WARNING:

ALWAYS ANCHOR GOAL
Unsecured Goal Can Fall Over
Causing Serious Injury or Death

⚠ WARNING:



NEVER CLIMB ON GOAL
Goal Can Fall Over Causing
Serious Injury or Death

Adult supervision is recommended when the goal is used by children.