



## ALUMINUM VALVE CAPS

### Instructions

1. Remove existing valve cap.
2. Check tire pressure and adjust to manufacturer's recommended pressure.
3. Replace with new valve cap.

Proper tire pressure improves gas mileage, handling, braking and durability.

**WARNING:** This product contains chemicals, including lead, known to the State of California to cause cancer, birth defects or other reproductive harm.

*Wash hands after handling.*

## TAPAS DE ALUMINIO PARA VÁLVULA

### Instrucciones

1. Quite la tapa de la válvula existente.
2. Revise la presión del neumático y ajústela según las recomendaciones del fabricante.
3. Reemplácela por la nueva tapa de la válvula.

La correcta presión del neumático ahorra gasolina y mejora la maniobrabilidad, la acción de los frenos y la durabilidad.

**ADVERTENCIA:** Este producto contiene sustancias químicas, incluyendo el plomo, que según el Estado de California causan cáncer, defectos congénitos u otro daño al sistema reproductor. *Lávese las manos después de usar el producto.*