

Easy Set Instructions for the EJ351C Timers

1. Move lever to the OFF/CLEAR position for 20-30 seconds to clear memory completely.
2. Move lever to the ON position. (indicator light will be flashing)
3. Rotate dial clockwise to the present time of day. (note the white side of dial is AM and the black side is PM) Press and release the dial to enter present time.
4. Rotate dial to select the time for the lights to turn on. Press and release the dial. (at this time the controlled lights will turn on)
5. Rotate dial to the times for the lights to go off. Press and release the dial. (at this time the controlled lights will turn off)
6. For additional programs repeat steps 4 and 5. If no additional times are required, move to step 7.
7. Rotate dial clockwise until the indicator light stops flashing and remains on solid. This is the indication that the timer has accepted the program. (note the dial does not function as a clock, it only moves when you turn it)

Special note: **when rotating the dial keep pressure pulling out to avoid accidentally entering incorrect time.**