

24228 – LitezAll Bug Zapping Lantern Operating Instructions and Precautions
04222001

Operation: Pressing the green button on top of the lantern cycles between lantern mode, ultraviolet bug zapping mode, combined mode and off.

Recharging: Plug the small end of the included charging cable into the charging port located directly below the power button. Plug the other end into any USB power source such as a power bank, USB wall charger, laptop, etc. The charging indicator light will glow red while charging and shut off when charging is complete.

Cleaning: With the lantern sitting on a flat surface, flip the 4 locking tabs located on each side of the lantern up. Lift the top portion of the lantern off. Tap the green guard lightly against a hard surface to remove debris. Dump debris out of the bottom portion. Place the top portion of the lamp back on to the bottom and press each locking tab until you hear or feel a click.

CAUTION: TO PREVENT ELECTRIC SHOCK DO NOT ATTEMPT TO REMOVE THE GREEN GUARD SURROUNDING THE ZAPPER. DO NOT INSERT OBJECTS INTO THE ZAPPER AREA.

Save these instructions and safety information.