

20985 - LA-300FL-6/24 Operating Instructions & Precautions 12032102

Operation: Repeatedly pressing the power button cycles between the brightness modes and off.

To focus the beam, hold the body of the light and twist the head to the desired degree of focus.

Battery Replacement: To replace battery, unscrew the cap at the bottom of the flashlight. Remove the old battery and insert 1 new CR123A, positive end first. Screw the cap back on tightly.

Caution: Do not install battery backwards, charge or put in fire. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (Ni-Cd, Ni-MH, etc.) batteries. This may cause batteries to leak or explode. Old or discharged batteries must be recycled or disposed of properly, according to local regulations.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions.