## 24662 – LA-RCHSFFL1-9/18 Operating Instructions and Precautions 09152001

**Charging:** This product is rechargeable. Please charge fully before first use to ensure optimal performance.

Plug the large connector of the included charging cable into any USB power source such as a power cube, computer or car charger. Pull back the charging port cover located below the power button and insert the other end of the charging cable. A red light above the charging port indicates charging is in progress. The light changes to green once charging is complete. Replace the charging port cover.

**Operation:** Repeatedly press the power button to cycle between high and low flashlight brightness modes plus white, solid red, flashing red lantern modes and off. The light also features an integrated flip up hanging loop in its base and a flat anti-roll tab below the flashlight head.

**Caution!** This product contains a non-replaceable rechargeable lithium battery. Attempting to open the product or replacing the rechargeable battery will result in permanent damage and void all warranties.

**Warning!** To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

**This product is not a toy!** Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions.