

# IMPORTANT

## 6300 Automatic Egg Turner



Use the thermometer supplied with the Little Giant® 9200 and 10200 Incubators which is mounted to a permanent plastic holder and is placed flat on top of the eggs.



**DO NOT MOVE EGG RAILS BY HAND.** The Egg Turner takes 4 hours to complete side to side movement; this movement can not be seen by the naked eye.



**DO NOT OVERLOAD THE EGG TURNER.** Overloading the egg turner may cause damage to the motor which will void the warranty.



Egg turner must be sitting flat on all four corners of the incubator for best hatching results.



If you have a 9200 or 10200 incubator without the power cord exit slots, you must add one. Use a screw driver or similar shaped object, lay it across the edge of the incubator and press down to form a slot for the egg turner power cord to exit the incubator. See product instructions.

P/N 6213 Rev 11/11

# IMPORTANT

## 6300 Automatic Egg Turner



Use the thermometer supplied with the Little Giant® 9200 and 10200 Incubators which is mounted to a permanent plastic holder and is placed flat on top of the eggs.



**DO NOT MOVE EGG RAILS BY HAND.** The Egg Turner takes 4 hours to complete side to side movement; this movement can not be seen by the naked eye.



**DO NOT OVERLOAD THE EGG TURNER.** Overloading the egg turner may cause damage to the motor which will void the warranty.



Egg turner must be sitting flat on all four corners of the incubator for best hatching results.



If you have a 9200 or 10200 incubator without the power cord exit slots, you must add one. Use a screw driver or similar shaped object, lay it across the edge of the incubator and press down to form a slot for the egg turner power cord to exit the incubator. See product instructions.

P/N 6213 Rev 11/11