




OWNER'S MANUAL

9" HIGH VELOCITY FAN



MODEL 1PAFHV9

SAFETY WARNING

SAFETY WARNING

Read this Instruction Manual carefully before assembling or operating the appliance and keep it for future reference.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. To reduce the risk of electric shock, **do not** immerse or expose this appliance or flexible cord to rain, moisture or any other liquid.
2. Dangerous high voltages are present inside this enclosure. To avoid electric shock, **do not** open the cabinet, refer servicing to qualified personnel only.
3. This appliance is intended for household use only and not for commercial, Industrial or outdoor use. Other use not recommended may cause fire, electric shock or injury.
4. Make sure the fan is not placed near drapes,curtains, or any objects that may be drawn into the fan. Never place or operate the unit where it could be subject to:
 - Heat sources such as radiators, heat registers, stoves or other products that produce heat
 - Direct sunlight
 - Excessive dust
 - Mechanical vibration or shock
 - Lack of ventilation
 - Uneven surfaces
5. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the product.
6. Ventilation should not be impeded by covering the ventilation openings. Slots and opening are provided for

ventilation to ensure reliable operation of the product and to protect it from overheating. Do not use with any opening blocked, keep free of dust, lint, hair and anything that might reduce airflow.


7. Place the fan on a stable level, dry surface when operating to avoid overturning.
8. Only connect to a AC120V~60Hz electrical socket.
9. Do not operate fan in the presence of explosive and/or flammable fumes. Do not place the fan near an open flame, cooking or other heating appliance.
10. Do not operate the fan with a damaged cord or plug, after a malfunction or if dropped or damaged in any manner.
11. Do not operate without the fan grills properly in place. Do not use if grill becomes damaged or loose.
12. Do not place the fan close to an open window. Rain splashing on the fan could cause an electric shock hazard.
13. Do not let the power cord hang over the edge of a table or counter or let it touch any hot surfaces.
14. Do not insert fingers or allow foreign objects to enter the grill openings as this may cause injury or damage to the appliance.
15. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
16. **⚠ WARNING** Children should be supervised to ensure that they do not play with the appliance.
17. Turn the fan OFF and unplug it from the outlet when not in use, when moving fan from one location to another and before cleaning.

SAFETY WARNING

(Continued)

18. To disconnect, grip the plug and pull it from the wall outlet. Never pull by the cord.
19. Switch off and unplug from wall outlet when not in use, before assembling or disassembling parts; and before cleaning. To avoid a tripping hazard, safely coil the cable.
20. Do not place this appliance on any flooring that may be marked or damaged by vibration of appliances.
21. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Do not attempt to repair, disassemble or modify the appliance by yourself. There are no user-serviceable parts inside.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.



NOTE: THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

SAFETY / OPERATION

POWER CORD SAFETY TIPS

- Never pull or yank on the cord or the appliance.
- To insert plug, grasp it firmly and guide it into outlet.
- To disconnect appliance, grasp plug and remove it from outlet.
- Before each use, inspect the power cord for cuts and/or abrasion marks. If any are found this indicates that the appliance should be serviced and the power cord replaced. Please return it to our Service Department or to an authorized Service Representative.
- Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.

⚠ CAUTION DO NOT OPERATE APPLIANCE IF THE POWER CORD SHOWS ANY DAMAGE, OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

NOTE: this fan comes fully assembled and is ready for use.

OPERATION INSTRUCTIONS

NOTE: During the first few minutes of initial use, you may notice a slight odor. This is normal and will quickly disappear.

Controlling The Fan Speed

- The speed control switch is located on the back of the rear grille.
- Press down switch to the desired speed setting Low-Off-High (I-O-II).

Adjusting The Tilt Of The Fan Head

To adjust the angle of the fan head simply move the fan head to the desired angle.

⚠ CAUTION

The fan should be switched off before making this adjustment.

MAINTENANCE

USER MAINTENANCE INSTRUCTIONS

Follow these instructions to correctly and safely care for your fan. Please remember :

- This fan requires little maintenance and contains no user serviceable parts. Do not try to fix it yourself. Return it to an authorized service facility if servicing is needed.
- This fan is permanently lubricated and will not require additional lubrication for the life of the fan.

USER SERVICE INSTRUCTION


This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

HOW TO REPLACE THE FUSE

Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover by sliding it towards blades. Then remove the fuse. Pry it out carefully (see below image). Replace the new fuse and push the cover back.

⚠ WARNING

Risk of fire. Replace fuse only rated with Max 5 Amp, 125Volt.



CARE/SPECIFICATIONS

CARE AND CLEANING

Machine will need more frequent cleaning if being used in an environment with high particle pollution.

- Always disconnect the fan from mains socket before cleaning.
- Avoid contact with moving fan parts.
- Use only a soft damp cloth to clean the fan.
- DO NOT immerse the fan in water and never allow water to drip into the Motor Housing.
- Never spray the appliance with liquids or submerge it in water or other liquid.
- DO NOT use gasoline, paint thinner or other chemicals to clean the fan.
- Ensure that the fan is switched off from the supply mains before removing the grill.
- Use a Phillips-head screwdriver to remove the screws located around the perimeter of the front grille.
- Remove front grille.
- Clean the fan blade and grills with a soft damp cloth.
- Store the fan in its original box or cover the fan to protect it from dust in a dry place if it will not be used for a long period of time.

⚠ CAUTION The fan blade may have sharp edges. Handle with extreme care.

SPECIFICATIONS

Power Supply: AC 120V ~ 60Hz

Power Consumption: 9 Inch-25W

Operation Temperature: 5-40°C

For your records, staple your sales receipt to this manual and record the following:

Date of Purchase: _____

Place of Purchase: _____

NOTE: Proof of purchase is required for all warranty claims.

NOTE: As a result of continual improvements, the design and specifications of the product within may differ slightly to the unit illustrated on the packaging.



SCAN CODE TO
LEAVE A REVIEW

THANK YOU FOR YOUR PURCHASE!

As a small business, reviews are everything!

We'd love to hear how you are enjoying your Perfect Aire product!
Please take a minute to tell us (and others) about your experience.

Thanks (again!)



5401 Dansher Road
Countryside, IL 60525

844-4PA-AIRE | 844-472-2473 | support@perfectaire.us
CANADA SUPPORT 877-997-2473 | supportcanada@perfectaire.us
www.perfectaire.us