

PRO-4 TACTICAL™

Flashlight 300 Lumens

Instruction Manual



Instructions

- Installing 3 AAA Alkaline Batteries
- Switching Modes/5 Power Settings
- Striker Head
- Zoom In/Out
- Maintenance
- Warning
- Troubleshooting

**Designed, Imported,
and Distributed by:**
Pro-4 Marketing

32411 Industrial Drive
Madison Heights, MI 48071

Tel: 248-809-2129 x2
Toll Free: 1-833-776-3687
www.Pro-4Marketing.com



QR CODE

14+
AGES

Installing 3 AAA Alkaline Batteries

- 1 Unscrew tail cap. Remove battery pack.
- 2 Insert 3 AAA batteries according to polarity (+/-) as indicated on battery pack.
- 3 Insert battery pack into flashlight with positive (+) end exposed. Replace tail cap.



FRESH ALKALINE BATTERIES ARE STRONGLY RECOMMENDED.
DO NOT MIX OLD AND NEW, OR DIFFERENT TYPES OF BATTERIES.


Switching Modes / 5 Power Settings

- 1 High Power Light
- 2 Medium Power Light
- 3 Low Power Light
- 4 Strobe Flashing Light
- 5 S.O.S. (Save our souls)

Auto High Mode: Turn OFF from any mode. Wait 10 seconds. Turn flashlight back ON and it will automatically turn on in "High Power Light" mode.


Striker Head

Striker Head surrounds Flashlight lens; use to scrape or break ice, and similar purposes.



Zoom In/Out

- 1 **Zoom In**
For a long, narrow, focused light beam: Pull OUT Flashlight head as shown.
- 2 **Zoom Out**
For a broader light beam: Push IN Flashlight head as shown.



Maintenance

- Remove and store batteries when not in use for 90 days or longer.
- Clean Flashlight with a clean, dry cloth as needed; dry after use.
- Lubricate screw threads and moving parts with standard consumer lubricant as needed.

Warning

- High Intensity Beam. Extremely bright 300 lumen light.
- Do not look directly into light; may cause vision damage.
- Follow City Ordinance Guidelines for proper disposal of dry cell batteries.
- Recommended for Ages 14+

Troubleshooting

If the Flashlight does not turn on; works intermittently; or has a weak light:

- Remove and replace batteries.
- Be sure battery pack is properly inserted. If problem persists, contact Pro-4 Tactical for technical advice.
- See www.Pro-4Marketing.com for Warranty and Replacement Information.

WARNING: This product can expose you to chemicals including Benzene and Ethylbenzene which are known to the State of California to cause cancer. For more information, go to www.p65Warnings.ca.gov

PRO-4 TACTICAL™

Flashlight 1 Year Warranty



No Questions Asked!

Pro-4 Tactical will repair or replace your non-working unit FREE of charge within One Year of Purchase. In order to register your Pro-4 Tactical product and be eligible for coverage under our 1-Year, No Questions Asked Warranty, please complete the product registration by mail or on our website.

Send Warranty Slip To: Pro-4 Marketing 32411 Industrial Drive, Madison Heights, MI 48071

- OR -

Register your unit online: www.Pro-4Marketing.com/warranty-registration.

Once you have registered you can make a claim to have your Pro-4 Tactical item replaced. In order to do this, you will need to send in the following: Proof of Purchase (store receipt); your contact information; a description of the problem; your non-working product.

NOTE: You MUST register your product before requesting service. Registration must take place within 2 weeks of purchase. You may also complete and send with the above items (within 2 weeks of purchase). If you do not have a store receipt, please indicate where and when you purchased your product.

PRO-4 TACTICAL PRODUCT REGISTRATION FORM

Name: _____

Address: _____

City: _____ State: _____ Zip: _____

Store Where Purchased: _____

Date of Purchase: _____

Month

Day

Year