



### **TIRE GAUGE**

You can improve your gas mileage by around 3.3% by keeping your tires inflated to the proper pressure. Under-inflated tires can lower gas mileage by 0.4% for every 1 psi drop in pressure of all four tires. Properly inflated tires are safer and last longer.

#### **Proper Use:**

- Check pressure before driving
- Make sure valve is free of dirt and debris
- Press gauge firmly onto valve stem and read PSI on indicator
- Reset dial by depressing pressure release button on side of unit
- Inflate to recommended pressure

**NOTE:** Do NOT over-inflate.

---

### **MEDIDOR DE AIRE**

Usted puede mejorar el rendimiento del combustible en alrededor del 3.3% al mantener sus llantas infladas a la presión indicada. Las llantas mal infladas pueden reducir el rendimiento de la gasolina en un 0.4% por cada disminución de 1 PSI en las cuatro llantas. Las llantas infladas correctamente son más seguras y duran más.

#### **Instrucciones de Uso:**

- Revisar la presión antes de manejar
- Asegurese que no haiga ningún objeto en la válvula
- Apriete el medidor en la válvula y lea el PSI (presión) en la varilla
- Reajuste el medidor presionando el boton de lanzamiento de la presion en el lado de la unidad.
- Infle a la presión recomendada

**NOTA:** NO sobre-infle.

PART# 20049

11.03.11



Accessories Marketing, Inc, a division of ITW, Inc.  
125 Venture Drive, Suite 210  
San Luis Obispo, CA 93401 USA  
P.O. Box 197  
Oaklands Park, SA 5046 Australia  
[www.slime.com](http://www.slime.com)  
Made in China