

SKABS & LEVERS

TUBE REPAIR INSTRUCTIONS



REMOVE TUBE FROM TIRE

Deflate tire completely and use tire levers to remove tire from rim.




LOCATE PUNCTURE

Remove tube from tire and locate puncture.



SCUFF AREA

Roughen puncture area with metal scuffer and wipe clean.



PEEL OFF SKAB BACKING

Do not touch backing or allow the adhesive to become contaminated.



APPLY SKAB

Place patch over puncture and press firmly.



REPLACE TUBE

Insert tube back into tire casing and reinflate tube.