

Tool Lanyard

Instruction Manual

Do not throw away these instructions!
Read and understand these instructions
before using equipment!

Part # 10726:
Tool Lanyard w/Mini Carabiner



Tool Lanyards **MUST NEVER** be
used for Fall Protection of any kind.

Length (including carabiner): 32"

Web Diameter: 1/2".

Materials: polyester, nylon, and aluminum.

MAXIMUM tool weight capacity: 20 lbs.

ONLY attach carabiner to harness web strap. NEVER tie knots in Guardian Tool Lanyards.

NEVER connect multiple Guardian Tool Lanyards to each other.

NEVER remove product labeling.



ALWAYS take extreme caution when operating or working near active machinery.

Maintenance, Cleaning, and Storage:

Proper care is important for maintaining the safety and longevity of Guardian Tool Lanyards. Before and after each use, remove all dirt, corrosives, and other contaminants from Guardian Tool Lanyards. If Guardian Tool Lanyards cannot be cleaned with plain water, use mild soap and water, then rinse and wipe dry, or allow to dry in an environment absent of excessive heat and light. When not in use, store equipment where it will not be affected by heat, light, excessive moisture, chemicals, or other corrosive elements.

Inspection:

Date of First Use: _____.

Record the Date of First Use in this instruction manual and on the inspection grid label on equipment. Product lifetime is indefinite, as long as product passes all inspection requirements.

Prior to EACH use, inspect Guardian Tool Lanyards for deficiencies including, but not limited to, corrosion, fraying, broken stitching, bird-caging, pits, burrs, rough surfaces, sharp edges, rust, paint buildup, excessive heating, alteration, and missing or illegible labels. Ensure carabiner gate fully opens and closes; gate must hold in closed position until compressed. IMMEDIATELY remove from service if defects or damage are found.

Inspection Log

	J	F	M	A	M	J	J	A	S	O	N	D
YR												
YR												
YR												
YR												
YR												

**If equipment fails inspection
IMMEDIATELY REMOVE FROM SERVICE.**

Every 12 months, a Competent Person other than the user must inspect Guardian Tool Lanyards. Competent Person inspections must be recorded in inspection log in these instructions and on equipment inspection grid label. The Competent Person must sign their initials in the box corresponding to the month and year of inspection.

Installation and Use:

1. Pull rope loop end through applicable tool.
2. Pull carabiner end through rope loop, and cinch lanyard tight around tool. NEVER attach tools in any other fashion. NEVER tie knots with Guardian Tool Lanyards.
3. Attach carabiner to compatible harness web strap. Carabiner gate must be fully closed.
4. Ensure no risk exists for carabiner to disconnect from harness, or for tool to disconnect from lanyard.

