


SEQUESTER™

Terminal Blocks

Blocs de jonction














Bloques de terminales





HOFFMAN (World Headquarters)
2100 Hoffman Way
Anoka, MN 55303-1745 USA
763 421 2240 Fax: 763 422 2178
Customer Service: (763) 422-2211
www.hoffmanonline.com

Canada
HOFFMAN
111 Grangeway Avenue
Suite 504
Scarborough, Ontario M1H 3E9
(416) 289-2770 Fax: 416 289 2883
1-800-668-2500 (Canada only)

Mexico
PENTAIR ENCLOSURES, S. de R.L. de C.V.
Federico T. de la Chica No. 8 Piso 4A
Circuito Comercial Plaza Satélite
Naucalpan, México C.P. 53100
525-3938263 Fax: 525-3938827

1  (2x)	2  30/60 Amp (4x)	3  30/60 Amp (4x)
4  100 Amp (3x)	5  100 Amp (3x)	6  Electrical Ground La Terre Électrique Tierra eléctrica (1x)
7  Electrical Ground La Terre Électrique Tierra eléctrica (1x)	8  200 Amp (3x)	9  200 Amp (3x)
10  (1x)	11  (1x)	12  (1x)
13  (1x)	14  M6 (4x)	





Blank Plate
Plaque de blanc
Adyacente de la lámina

