

Fairfax® Essentials Performance Showering Package K-10826-4

Features

- Performance showering packages offer increased functionality and simplify the ordering process.
- Single lever handle provides on/off activation and temperature setting with a single operation.
- Multifunction showerhead offers wide coverage, therapeutic massage, and soft aerated spray settings.
- Multifunction handshower offers wide soft coverage, soft pulse, and soft aerated spray settings.
- Includes handshower, showerhead, showerarm with diverter, shower hose, slidebar kit, and Rite-Temp valve trim.
- Coordinates with Fairfax® faucets and accessories.
- KOHLER finishes resist corrosion and tarnishing.

Installation

- Wall-mount
- Trim only; requires K-304 Rite-Temp pressure-balancing valve (sold separately).

Required Products/Accessories

K-304/K-P304 Series Rite-Temp® Valves

or

K-8304/K-P8304 Series Rite-Temp ${\ensuremath{\mathbb R}}$ Valve & Cartridge Kits or

K-8300/K-P8300 Series Rite-Temp® Valve Body Rough-ins K-8305/K-P8305 Series Rite-Temp® Cartridges

or

K-2971-KS 3/4" Pressure-balancing Valve

Included Components

Product consists of: K-9514 60" Shower Hose K-9511 Showerarm and Diverter K-8524 30" Slidebar K-12009 Multi-function Showerhead K-T12021-4 Rite-Temp® Valve Trim K-349 Slidebar Trim Kit 1055527 Handshower Relaxing



Codes/Standards

ASME A112.18.1/CSA B125.1 DOE - Energy Policy Act 1992

KOHLER[®] Faucet Lifetime Limited Warranty

See website for detailed warranty information.

Available Colors/Finishes

Color tiles intended for reference only.

Color Code Description

CP
BN


- CP Polished Chrome
- BN Vibrant® Brushed Nickel
- 2BZ Oil-Rubbed Bronze



Fairfax®

KOHLER. Faucets

Essentials Performance Showering Package K-10826-4



Technical Information

All product dimensions are nominal.

Handshower:

Rated maximum flow:2.5 gal/min (9.5 l/min)Pressure:80 psi (5.5 bar)

Showerhead/Body Spray:

Rated maximum flow:2.5 gal/min (9.5 l/min)Pressure:80 psi (5.5 bar)

Notes

Install this product according to the installation guide.

Install the Rite-Temp® valve according to the valve installation guide.

