



Wiremold

TableSource™

Work Surface Modules

## INSTALLATION INSTRUCTIONS



Installation Instruction No.: 42073R1 – Updated December 2011

Legrand/Wiremold electrical systems conform to and should be properly grounded in compliance with requirements of the current National Electrical Code or codes administered by local authorities.

All electrical products may present a possible shock or fire hazard if improperly installed or used. Legrand/Wiremold electrical products may bear the mark of a Nationally Recognized Testing Laboratory (NRTL) and should be installed in conformance with current local and/or the National Electrical Code.


**IMPORTANT: Please read all instructions before beginning.**

### INSTALLATION:





**NOTE:** Use No. 8 (5/16" [7.9mm] head size) flat head fastener or equivalent to secure mounting clip onto table surface (top or bottom).


### REMOVAL:




**ASSEMBLY:**



**INSTALLATION:**



**REMOVAL:**



**Wiremold**

**WIREMOLD**

**U.S. and International:**

60 Woodlawn Street • West Hartford, CT 06110  
1-800-621-0049 • FAX 860-232-2062 • Outside U.S.: 860-233-6251

**Canada:**

570 Applewood Crescent • Vaughan, Ontario L4K 4B4  
1-800-723-5175 • FAX 905-738-9721

