

Size Chart


	CHEST	WAIST	HIP (SEAT)
SMALL	34 - 36	28 - 30	34 - 36
MEDIUM	38 - 40	32 - 34	38 - 40
LARGE	42 - 44	36 - 38	42 - 44
XL	46 - 48	40 - 42	46 - 48
2XL	50 - 52	44 - 46	50 - 52
3XL	54 - 56	48 - 50	54 - 56
4XL	58 - 60	52 - 54	58 - 60
5XL	62 - 64	56 - 58	62 - 64
6XL	66 - 68	60 - 62	66 - 68

Units are expressed in inches and reflect general body dimensions.
Measurements are approximate.

Men’s Performance Fit Jackets

- Back Length: 27”- 30”
- Length sits slightly above hip to at hip, depending on style

Use the illustration below to compare the lengths of our outerwear.



Vests
26" - 29"


Jackets
26" - 30"

**Performance
Fit Jackets**
27" - 30"

**Coats &
Parkas**
30.5" - 36"

How to Measure

Note: For best results measure over your undergarments. Use a cloth measuring tape.



Chest:

Measure just under arms and across shoulder blades holding the tape firm and level. If your chest falls between sizes, order the next size up.

Natural Waist:

Bend side to side and find the natural bend in your body; this is your natural waist. Note: It may not be the smallest point.