

**EASY-OFF® FUME FREE OVEN CLEANER**  
penetrates tough baked-on grease with no fumes and safe for self-cleaning ovens.



STEP 1

STEP 2

STEP 3

To ensure complete dispensing during life of product:

Ideal for cleaning ovens/oven doors, broilers/broiler pans, and stainless steel surfaces.



**READ ENTIRE LABEL BEFORE USE AND FOLLOW DIRECTIONS. SHAKE CAN WELL AND FREQUENTLY DURING USE. BE SURE TO POINT ARROW TOWARDS DIRECTIONAL DOT AND AWAY FROM FACE. USE IN COLD OVEN. DO NOT CLEAN DOOR GASKET - THE DOOR GASKET IS ESSENTIAL FOR A GOOD SEAL. CARE SHOULD BE TAKEN NOT TO RUB, DAMAGE, OR MOVE THE GASKET.**

**PRECAUTIONS:** • Do not spray on pilot light, electrical connections, switches, heating elements, or thermostats. • Do not spray onto aluminum or painted surfaces as damage to these surfaces may occur. • Do not use on microwave, convection, or continuous-cleaning ovens. Can be used on self-cleaning ovens provided that the self-cleaning cycle is not used in combination with EASY-OFF® FUME FREE Oven Cleaner.

#### USE INSTRUCTIONS

##### DEEP CLEANING

**1. SPRAY IN COLD OVEN.** If you have a self-cleaning oven, make sure self-cleaning cycle is turned off and oven is cold. Hold can upright, pointed away from face. Spray top of oven first by pointing arrow on spray button to DOT. Then spray sides and bottom of oven. Spray cold oven surfaces from a distance of 9-12 inches, making sure that soiled surfaces are well covered. **2. CLOSE DOOR. WAIT 1 HOUR 15 MINUTES FOR THE FOAM TO PENETRATE OVEN SOILS.** Do not turn oven or self-cleaning cycle on. For tougher stains, allow foam to remain overnight. Do not turn oven or self-cleaning cycle on. **3. WIPE CLEAN.** Use a wet sponge, cloth or paper towels, rinsing frequently with warm potable water.

##### DAILY SPOT CLEANING

**1. SPRAY IN COLD OVEN.** Hold can upright, pointed away from face. Liberally spray spots from a distance of 9-12 inches by pointing arrow on spray button to DOT. **2. ALLOW TO STAND** for 30 sec. - 1 min. **3. WIPE CLEAN** with a wet sponge, cloth or paper towels.

#### KEEP OUT OF REACH OF CHILDREN

**CAUTION:** EYE IRRITANT. CONTENTS UNDER PRESSURE.

Contains Ethanolamine and Dipropylene Glycol Propyl Ether

**DO NOT** get in eyes. Wash hands after application and removal.

**DO NOT** puncture or incinerate container. **DO NOT** expose to heat or store at temperatures above 120° F (49° C).

**FIRST AID:** If in eyes, IMMEDIATELY flush eyes with water. Remove any contact lenses and continue to flush eyes for at least 15 minutes. If irritation persists, seek medical attention.

Contains no phosphorus.

**Ingredients:** Water, Dipropylene Glycol Propyl Ether, Isobutane, Potassium Carbonate, Ethanolamine, Smechtite Clay, Benzyl Alcohol, Sodium Lauryl Sarcosinate, Paraffin Wax, Fragrance. Contains fragrance allergens.

**Questions? 1-800-228-4722**

For more ingredient information visit [www.rbmainfo.com](http://www.rbmainfo.com)  
US Patents: [www.rb.com/patents](http://www.rb.com/patents)

Distributed by: Reckitt Benckiser  
Parsippany, NJ 07054-0224  
© 2020 RB 3149466



# NO GLOVES REQUIRED

# EASY-OFF®

## OVEN CLEANER

### FUME FREE SAFE FOR SELF-CLEANING OVENS

**30** GREAT FOR  
SEC SPOT CLEANING

### DESTROYS TOUGH BURNED-ON FOOD & GREASE



KEEP OUT OF REACH OF CHILDREN

**CAUTION:** EYE IRRITANT.  
CONTENTS UNDER PRESSURE.  
Read precautions on back.



PLEASE RECYCLE  
WHEN EMPTY

NET WT.: 14.5 OZ. (411 g)