

Installation Requirements of Push-EMT[®] Product Lines: Mighty-Bite[®] and Mighty-Seal[®]



Mighty-Bite[®]



Mighty-Seal[®]

Bridgeport Fittings new Push-EMT product lines offer the quickest installation of any fittings currently on the market. The following product attributes should be noted by any customers not familiar with these fittings.

1) Careful preparation is required of cut ends.

The Push-EMT installer should be careful to remove all burrs, and to fully chamfer the inner and outer edge after any cuts are made.

2) The fitting or EMT should be rotated when installing.

Rotate the Mighty-Bite and Mighty-Seal fittings a quarter turn when installing on EMT. This is especially critical in the 3/4 inch trade size. A slight rotation will allow the fittings to be installed with relative ease.

3) Mighty-Seal fittings are removed by disassembly. Mighty-Bite fittings simply unscrew.

4) Mighty-Bite fittings are reusable, but the EMT may need to be re-prepared after removal.

The Mighty-Bite fittings create score marks as the fitting is threaded on. During removal, the fitting (connector or coupling) follows these score lines as the fitting is rotated off of the EMT. This creates deep grooves which may hinder the functionality of the fitting if it is removed and reinstalled several times. As a rule of thumb: *Mighty-Bite fittings should **not** be removed and reinstalled from the same end of EMT more than two times.*

5) Mighty-Seal fittings can be reused up to 3 times as long as the green O-ring has been inspected for damage after each use.