

26697 - LA-6VFLAN-3-12 Operating Instructions and Precautions 09062301

Operation: Repeatedly pressing the power button cycles between on and off.

Battery Replacement: Unscrew the battery compartment cap on the back of the light. Remove expired batteries. With the handle facing up, insert 1 new alkaline battery in each of the top 3 chambers. From left to right, insert them negative end first, positive end first and negative end first.

Replace the battery compartment cover by lining up the raised tab on the long stem with the slot in the center hole in the battery compartment. Screw the battery compartment cap back on. **CAUTION: Do not cross thread!**

Internal Battery Storage: The bottom 3 chambers are for storing up to 6 extra batteries only. They DO NOT power the light. You may insert up to 2 batteries in each storage chamber in any orientation.

Caution: Replace all batteries at the same time. Do not install batteries backwards, charge or put in fire. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc.) Batteries. This may cause batteries to leak or explode. Old or discharged batteries must be recycled or disposed of properly, according to local regulations.

Warning! To prevent serious injury, including temporary or permanent loss of sight do not stare into the light, shine light into eyes or focus the beam using an additional lens. Keep away from infants and toddlers as this product contains small parts.

This product is not a toy! Use this light only as it is intended. Inspect before every use. Do not use if parts are damaged, loose or missing.

Save these safety precautions!