

# Installation Instructions 151SR/K151SR Straight Receptacle

CONTENTS: Straight Receptacle, Conductor Contact (male), Nylon Venting Rod, Lubricant, Crimp Chart, Installation Instructions.

The 151SR/K151SR is designed to connect lengths of solid dielectric type cable to one another or to electrical apparatus by mating with other ELASTIMOLD products that are also designed for these functions. The 151SR/K151SR mates with the following ELASTIMOLD products: 151SP/K151SP, 150T/K150T, 150DP/K150DP, 1501A1/K150A1, 180/K180 series bushings, 600RTP(S)/K600RTP(S).

The 151SR is for use on15kV class systems (8.3kV phase-to-ground). The K151SR is for use on 25kV class systems (15.2kV phase-to-ground).

**CAUTION:** A bailing arrangement is required when this product is used with any mating Elastimold deadbreak product.

#### **DANGER**

All apparatus must be de-energized during installation or removal of part(s). For loadbreak products follow operating instructions.

All apparatus must be installed and operated in accordance with individual user, local, and national work rules. These instructions do not attempt to provide for every possible contingency.

Do not touch or move energized products by hand.

Excess distortion of the assembled product may result in its failure.

Contact with solvents, transformer oil, motor oil and similar substances will degrade jacket conductivity and insulation level if not immediately wiped off.

Inspect parts for damage, rating and compatibility with mating parts.

This product should be installed only by competent personnel trained in good safety practices involving high voltage electrical equipment. These instructions are not intended as a substitute for adequate training or experience in such safety practices.

Failure to follow these instructions will result in damage to the product and serious or fatal injury.

If this product is supplied with a protective shipping cover(s), remove this shipping cover(s) and replace with the appropriate HV insulated cap(s) or connector(s) before submerging or energizing the circuit.


FOR MORE INFORMATION ON PARTS, INSTALLATION RATINGS AND COMPATIBILITY, CALL THE NEAREST ELASTIMOLD OFFICE.

#### **IMPORTANT**

- Check contents of package to insure they are complete and undamaged.
- Check all components to insure proper fit with cable and/or mating products.
- 3. Read entire installation instructions before starting.
- 4. Have all required tools at hand and maintain cleanliness throughout the procedure.


# **STEP 1A Jacketed Concentric Neutral**

Cut Cable. Cut and remove cable jacket a distance of 8" from cable end. When cutting cable, allow sufficient concentric neutral wires for connecting to ground point as required by the installation.



# STEP 1B Copper Tape Shield

Cut cable. \*Cut and remove cable jacket a distance of  $7^{1/2}$ " from cable end. Remove copper tape shield a distance of  $6^{1/2}$ " from end of cable.




\*When using an ECS or MA grounding device, follow the appropriate installation instructions regarding outer jacket cut back.




### STEP 2

Remove <sup>7</sup>/<sub>8</sub>" to 1" (1 <sup>3</sup>/<sub>4</sub>" to 1 <sup>7</sup>/<sub>8</sub>" for #1 stranded/compr. and #1/0 comp./solid aluminum cable) of cable insulation and conductive shield. *Wire brush bare aluminum conductors and immediately insert into crimp barrel which contains inhibitor*. Cut squarely, DO NOT PENCIL.




# STEP 3

Crimp socket terminal on the bared conductor while ensuring conductor remains fully seated in connector. (See crimp chart packed with contact). Start the crimps at crimp line imprinted on crimp barrel and rotate each successive crimp or indent 90°. When using aluminum cable, carefully wipe excess inhibitor from the contact and cable insulation.




## STEP 4

- A. Remove the semi-conductive shield to a point 7  $^9/_{16}$ " to 7  $^5/_8$ " back from the end of the pin with straight, smooth, "squared" cut. DO NOT CUT OR NICK THE INSULATION.
- B. Pencil insulation  $\frac{1}{8}$ ".
- C. Clean the outer jacket and thoroughly clean the insulation to remove all traces of semi-conducting residue. This may be done by wiping with a rag wet with an approved solvent. Always wipe from the end of the cable toward the outer jacket.
- D. If using an ECS or MA grounding device, install the device following the appropriate installation instructions.



#### STEP 5

Remove protective cap from the straight receptacle. Keep cable insulation and receptacle clean. Apply supplied lubricant sparingly to the cable as shown and to the inside of the housing. DO NOT SUBSTITUTE. Other lubricants may be harmful to this product or its mating product.




#### STEP 6

Push cable into housing until the base of the pin chamfer is flush with the inside face of the receptacle.

**IMPORTANT:** If receptacle is not to be immediately connected, replace protective cover.


SHIPPING COVER OFFERS PROTECTION FROM DIRT ONLY. IT IS NOT AN INSULATING DEVICE! IF AN INSULATING DEVICE IS REQUIRED, OBTAIN AN ELASTIMOLD INSULATING PLUG (K150DP).




# STEP 7

To connect to a mating plug:


A. Lubricate nose of plug with silicone grease.



B. Place nylon rod into receptacle face until it bottoms (approximately 1 <sup>3</sup>/<sub>4</sub>"). Care should be used to ensure the nylon rod is not cut while mating parts, leaving material inside upon the interface.



- C. Insert plug assembly into receptacle as far as possible.
- D. Pull out nylon rod.




E. Secure the electrical connection with the aid of an Elastimold bail.

# STEP 8

Cable Grounding:

If an ELASTIMOLD grounding device is not being used, connect a length of (#14 AWG or equivalent) copper wire (customer supplied) thru the grounding tab and twist tightly as shown. Then connect the grounding assembly of the connector to the system ground by merging with the cable shield of each cable. Seal the grounding wires and connections to prevent corrosion.





Esna Park Drive, Hackettstown, New Jersey 07840 USA (908)852-1122 FAX: (908)813-2147

A Unit of Thomas & Betts Corporation