## Airow 3 Hydrogen Peroxide Air Cleaner



**TADIRAN Airow 3™** is a unique Hydrogen Peroxide Air Treatment System designed to reduce airborne pathogens in your home. With its robust design and effective air treatment capabilities, Airow 3 reduces SARS-CoV-2, viruses, bacteria, and mold\* to promote a healthier indoor environment. Specifically designed for mini-split AC systems and ceiling cassettes, Airow 3 safely operates without emitting ions, requires no maintenance, and is incredibly easy to install with its plug-and-play functionality.

## **Features**

- Reduces up to 99% of bacteria, viruses, and mold
- FDA-cleared lab has thoroughly tested and approved its effectiveness
- Best-in-class air treatment technology, taking a proactive approach to treat the air
- Requires zero maintenance ensuring a hassle-free operation
- Maintains lasting effectiveness, even when the AC system is turned off
- Simple installation process
- Applicable homes, commercial spaces, schools, new construction, hotels, senior living facilities, and more
- Zero Ozone









252.522.3031 fieldcontrols.com sales@fieldcontrols.com

## **How It Works**

TADIRAN AIROW 3<sup>TM</sup> uses a discharge current to break apart Oxygen (O₂) molecules into two separate O atoms. The free oxygen atoms combine with water (H₂O) molecules in the airflow and transform into purifying Hydrogen Peroxide (H₂O₂). The H₂O₂ is then distributed into the indoor space by the air conditioning unit. When the H₂O₂ encounters viruses, bacteria, mold, or other airborne contaminants, it breaks down the exterior structures, thus inactivating and reducing aerosol pathogens.



Bioaerosol Type	Species/Protocol	Testing Lab	Results
Bacteria	Streptococcus pyogenes (Group A) Chamber size: 36m³, after 120 min Staphyloccocus Epidermis vegetative (+) Chamber size: 1m³, after 60 min	Innovative Bioanalysis Labs, USA  Aerosol Research and Engineering Laboratories, USA	100% <sup>2</sup> 99.994% <sup>9</sup>
Virus	SARS-CoV-2 Chamber size: 16m³, after 60 min	Innovative Bioanalysis Labs <sup>,</sup> USA	99.93% 7
Virus	RNA Virus MS2 Bacteriophage Chamber size: 1m3, after 60 min	Aerosol Research and Engineering Laboratories, USA	99.994% 8
Mold Spore	Blue Mold (Penicillium Citrinum) Aerosolized Chamber size: 25m3, after only 3 hours	Kitazao Laboratory, Japan	99.4% 10
Ozone Emission	UL 867 Section 40	INTERTEK	<5 ppb <sup>5</sup> Tested

- <sup>1</sup> TADIRAN AIROW 3 device was tested in the US-based internationally recognized laboratory Innovative Bioanalysis, which is BSL3 accredited.
- <sup>2</sup> TADIRAN AIROW 3 reduced the aerosol of Streptococcus pyogenes in 36 cubic meter test chamber, by 100% within 120 min.
- ³ Independent tests commissioned by Tadiran showed that TADIRAN AIROW™ technology eliminated known aerosolized pathogens under optimal testing conditions. To learn more about the tests, visit www.tadiran-international.com/scientific-testing.
- Only qualified and licensed HVAC technicians may install TADIRAN AIROW.
- <sup>5</sup> TADIRAN AIROW is verified as zero ozone. Does not emit more than 0.005PPM as tested per UL 867.
- <sup>6</sup> World Health Organization EPA report on the environment https://www.epa.gov/report-environment/indoor-air-quality. Pre COVID-19.
- <sup>7</sup> TADIRAN AIROW 3 reduced detected SARS-CoV-2 aerosol levels by 99.93% within 1 hour (16 cubic meter test chamber).
- <sup>8</sup> TADIRAN AIROW 3 reduced MS2 levels by 99.994% in 1 hour (1 cubic meter test chamber).
- 9 TADIRAN AIROW 3 reduced detected Bacteria Staphylococcus epidermidis aerosol levels by 99.994% within 1 hour (1 cubic meter test chamber)
- <sup>10</sup> TADIRAN AIROW 3 reduced Aerosol of Blue Mold by 99.4% within 3 hours in a 25m³ chamber.
- $^{11}$  TADIRAN AIROW 3 creates <15 ppb  $\rm H_2O_2$  based on a test conducted by LSC Laboratory inc.
- <sup>12</sup> TADIRAN AIROW 3, tested by TUV and Intertek, does not emit more than 0.005PPM.
- <sup>13</sup> All pictures shown are for illustration purposes only. Actual product may vary.



