


# **TEMPER ANCHOR**

ANCHORAGE CONNECTOR

## FEATURES 5 BENEFITS



### **SPECIFICATIONS**

#### **STANDARDS:**

OSHA 1926 Subpart M & 1910 ANSI Z359.18-17 & A10.32-12

Type A Anchorage Connector

#### **MATERIALS:**

Zinc-plated Steel

#### **WORKER CAPACITY:**

130-420 lbs.

#### PERFORMANCE:

- Maximum Users: 1
- 5,000 lb. MBS (Minimum Breaking Strength)

#### **NOTES:**

- Minimum service temperature: -30°F
- Installs on wood, metal, or concrete
- All fasteners must be fully embedded in substrate. Applicable roof pitches: flat to sheer
- Anchor must install flush against substrate. Never install onto bare truss.

PART #	DESCRIPTION	WEIGHT
00455	Temper Roof Anchor	3.5 Lbs

## **APPLICATIONS**



#### PERSONAL FALL ARREST:

Temper Anchors may be used in Personal Fall Arrest applications to support:

- MAXIMUM 1 Personal Fall Arrest System (PFAS).
  Structure must withstand loads applied in the directions permitted by the system of at least 5,000 lbs.
- Maximum free fall is 6'.
- Applicable D-rings: Dorsal.



#### **WORK POSITIONING:**

Temper Anchors, configured with side or shoulder D-rings, may be used in Work Positioning applications.

- Work Positioning systems allow a worker to be supported while in suspension and work freely with both hands.
- Structure must withstand loads applied in the directions permitted by the system of at least 3.000 lbs.
- Maximum allowable free fall is 2'.
- Applicable D-Rings: Side & Shoulder.



#### **RESTRAINT:**

Temper Anchors may be used in Restraint applications. Restraint systems:

- Prevent workers from reaching the leading edge of a fall hazard. Always account for fully deployed length of lanyard/SRL.
- Structure must withstand loads applied in the directions permitted by the system of at least 1,000 lbs.
- No free fall is permitted.
- May only be used on surfaces with slopes up to 4/12 (vertical/horizontal).
- Applicable D-rings: Dorsal, Chest, Side, & Shoulder.









