

# Mistos® Rite-Temp®

bath and shower trim set, 1.75 gpm **K-R37028-4G** 

#### **Features**

- Single lever handle allows for simultaneous on/off activation and temperature setting.
- 1.75 gpm (gallons per minute) showerhead flow rate.
- Rite-Temp® pressure-balancing technology maintains water temperature within +/- 3°F.
- Katalyst® air-induction technology maximizes the air/water mix for a powerful, even flow.
- MasterClean<sup>™</sup> sprayface features an easy-to-clean surface that withstands mineral buildup.
- Coordinates with other products in the Mistos collection.

#### Material

- Premium metal construction for durability and reliability.
- KOHLER finishes resist corrosion and tarnishing.

#### Installation

- Heavy duty slip-fit clamp design and NPT threaded spout.
- Wall-mount

## **Recommended Products/Accessories**

K-23723 Faucet cleaner

# **Optional Products/Accessories**

1073881 Deep Rough-in Kit 88526 Thin Wall Trim Kit

## **Included Components**

Additional Components: 1.75 gpm showerhead Diverter spout

Shower arm and flange Valve trim plate





# Codes/Standards

ASME A112.18.1/CSA B125.1 ASSE 1016/ASME A112.1016/CSA B125.16 DOE - Energy Policy Act 1992 EPA WaterSense® California Energy Commission (CEC)

# KOHLER® Faucet Lifetime Limited Warranty

See website for detailed warranty information.

## Available Colors/Finishes

Color tiles intended for reference only.


Color	Code	Description
	CP	Polished Chrome
-	BN	Vibrant® Brushed Nickel





# Mistos® Rite-Temp®

bath and shower trim set, 1.75 gpm **K-R37028-4G** 



# **Technical Information**

All product dimensions are nominal.

Drain included: No

# Showerhead/Body Spray:

Rated maximum flow: 1.75 gal/min (6.6 l/min)

#### **Notes**

Install this product according to the installation instructions.

Install straight pipe or tube drop of 7" (178 mm) to 18" (457 mm) with single elbow between the valve and the wall-mount spout.

NOTICE: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit is needed.

