



Sakrete® NoMix® PostSet® is a quality mixture of sand, cementitious materials and special additives. For setting fence, lamp and mailbox posts, porch and deck supports, swing sets, basketball goal posts, clothesline posts, metal, wood and vinyl posts without mixing or bracing. (Not to be used for Footings).

Features:

- No mixing required
- Hardens in 15 minutes

Use For:

- Setting posts and poles

Yield/Water/Coverage:

To determine the amount of material needed to set posts for dimensions not provided in the table below, use the calculator available on Sakrete.com

Setting 2" (51 mm) Round Posts				
	6" (152 mm) diameter hole	8" (203 mm) diameter hole	10" (254 mm) diameter hole	12" (305 mm) diameter hole
12" (305 mm) deep	0.5	1	1.5	2.5
18" (457 mm) deep	1	1.5	2.5	3.5
24" (610 mm) deep	1	2	3	5
30" (762 mm) deep	1.5	2.5	4	6

Setting 3" (76 mm) Round Posts				
	6" (152 mm) diameter hole	8" (203 mm) diameter hole	10" (254 mm) diameter hole	12" (305 mm) diameter hole
12" (305 mm) deep	0.5	1	1.5	2.5
18" (457 mm) deep	1	1.5	2.5	3.5
24" (610 mm) deep	1	2	3	4.5
30" (762 mm) deep	1	2.5	4	6

Setting 4" (102 mm) Round Posts				
	6" (152 mm) diameter hole	8" (203 mm) diameter hole	10" (254 mm) diameter hole	12" (305 mm) diameter hole
12" (305 mm) deep	0.5	1	1.5	2.5
18" (457 mm) deep	0.5	1	2	3.5
24" (610 mm) deep	0.5	1.5	3	4.5
30" (762 mm) deep	1	2	3.5	5.5

Setting 4" x 4" (102 x 102 mm) Square Posts				
	6" (152 mm) diameter hole	8" (203 mm) diameter hole	10" (254 mm) diameter hole	12" (305 mm) diameter hole
12" (305 mm) deep	0.5	1	1.5	2
18" (457 mm) deep	0.5	1	2	3.5
24" (610 mm) deep	0.5	1.5	3	4
30" (762 mm) deep	1	2	3.5	5

NOTE: Yield and water are approximate. The yield above does not allow for waste and spillage.

Color: Gray

Mixing:

1. Dig hole to recommended specifications. Fill hole about half-full with clean water.
2. Place post in hole and pour PostSet at a steady, even rate around the post into the water. Bring dry powder up to the surface of the water. (Refer to chart for PostSet requirements.)
3. Align post to desired position. PostSet will harden in approximately 5 minutes.
4. Sprinkle water on top of the PostSet powder visible in the hole. Tamp surface to eliminate air cavities.

Do not machine mix or hand mix. At 70°F (21°C) PostSet will set in approximately 5 minutes. Cold weather will slightly retard the set time. Hot weather will slightly accelerate the set time.

Precautions:

Air, mix and substrate temperatures should be between 40°F (4°C) and 90°F (32°C) and no rain in the forecast within 24 hours of application. For applications outside this range of temperatures and conditions, contact Sakrete Technical Service.

- Colder temperatures or higher humidity conditions will retard set times
- Protect from freezing for 24 hours

NOTE: Proper application and installation of all Sakrete products are the responsibility of the end user.

Safety:

READ and UNDERSTAND the Safety Data Sheet (SDS) before using this product. WARNING: Wear protective clothing and equipment. For emergency information, call CHEMTREC at 800-424-9300 or 703-527-3887 (outside USA). KEEP OUT OF REACH OF CHILDREN.

Limited Product Warranty:

The manufacturer warrants that this product shall be of merchantable quality when used or applied in accordance with the manufacturer's instructions. This product is not warranted as suitable for any purpose other than the general purpose for which it is intended. This warranty runs for one (1) year from the dates the product is purchased. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THIS WARRANTY. Liability under this warranty is limited to replacement or defective products or, at the manufacturer's option, refund of the purchase price. CONSEQUENTIAL AND INCIDENTAL DAMAGES ARE NOT RECOVERABLE UNDER THIS WARRANTY.